



TROMSØ


# TALL BOY

Item Code: 395662

## Assembly Instructions


**1.0hr**

APPROXIMATE ASSEMBLY TIME




2 PEOPLE ASSEMBLY

FLOOR AREA  
3Mx3M




REQUIRED ASSEMBLY SPACE


REQUIRED ASSEMBLY TOOLS



UBBER HAMMER(Not Provided)



SLOTTED SCREWDRIVER(Not Provided)




POZZI SCREWDRIVER(Not Provided)



MEASURING TAPE(Not Provided)

ASSEMBLED DIMENSIONS



MAX. LOADING: 15KG (3KG PER SHELF)


# TROMSO TALL BOY

Item Code: 395662

## Assembly Instructions

NO.	PART LIST	QTY	NO.	PART LIST	QTY
(1)	TOP PANEL	1	(8)	DOOR	1
(2)	DIVISION PANEL	1	(9)	SHELF PANEL	2
(3)	BOTTOM PANEL	1	(10)	INTERNAL SHELF	1
(4)	TOP LEFT SIDE PANEL	1	(11)	METAL FEET	2
(5)	BOTTOM LEFT SIDE PANEL	1	(12)	METAL SUPPORT BAR	2
(6)	TOP RIGHT SIDE PANEL	1	(13)	BACK PANEL	2
(7)	BOTTOM RIGHT SIDE PANEL	1			

### PART LIST



















# TROMSO TALL BOY

## Item Code: 395662

### Assembly Instructions

#### HARDWARE LIST

<b>A</b>	<b>x20</b>	<b>B</b>	<b>x20</b>	<b>C</b>	<b>x4</b>	<b>D</b>	<b>x4</b>	<b>E</b>	<b>x1</b>
				 Dia:4x25mm		 Dia:6x30mm			
PIN		CAM LOCK		SCREW		BOLT		ALLEN KEY	
<b>F</b>	<b>x1</b>	<b>G</b>	<b>x1</b>	<b>H</b>	<b>x1</b>	<b>I</b>	<b>x2</b>	<b>J</b>	<b>x1</b>
		 Dia:4x12mm				 Dia:3x14mm			
ANTI-TIP STRAP		SCREW		WALL PLUG		SCREW		MAGNET	
<b>K</b>	<b>x1</b>	<b>L</b>	<b>x1</b>	<b>M</b>	<b>x19</b>	<b>N</b>	<b>x5</b>	<b>O</b>	<b>x6</b>
						 Dia:4x35mm			
MAGNET STRIP		HANDLE		BACK PANEL PIN		SCREW		SHELF SUPPORT	
<b>P</b>	<b>x3</b>								
 Dia:3x12mm									
SCREW									

# TROMSO TALL BOY

Item Code: 395662

## Assembly Instructions



### Safety Advice and Care Advice

KEEP ALL THE SAFETY ADVICE AND INSTRUCTIONS IN A SAFE PLACE FOR FUTURE REFERENCE!



### **WARNING! RISK OF LOSS OF LIFE OR ACCIDENT**

**TO INFANTS AND CHILDREN!** Never leave children unsupervised with the packaging materials. Danger of suffocation.



**CAUTION! RISK OF INJURY!** Make sure that all parts are undamaged and assembled correctly. Improper assembly carries a risk of injury. Damaged parts may affect the safety and function of the product.

- Adult assembly required.
- Power tools are not recommended for the assembly of this product.
- Make sure that this product is stable & used only on a solid & flat surface.
- Do not use this product unless all screws and fixings are firmly secured.
- Do not leave children unsupervised! The product is not a climbing frame or a toy!
- Do not stand, sit or lean on this product.
- Do not use this product as a step ladder or as a chopping surface.
- Do not lift or move the product when it is loaded.
- Do not load more than a total of 15kg (3kg per shelf) per each table onto the unit, otherwise there is a risk of injury and/or damage to the product.
- Distribute weight evenly across the product so that it cannot overturn.
- Do not place hot items such as coffee cups directly on the surface(s) unless adequately thick table mats are used.
- Please periodically check all fittings and re-tighten as necessary.
- For Indoor & Domestic use only.

### **Care instructions:**

- Wipe clean with a dry cloth.
- Do not use scourers, abrasive or chemical solvents.
- Keep away from moisture and direct sunlight.
- Keep away from fire and inflammable objects.
- Store in a dry place.


# TROMSO TALL BOY

Item Code: 395662



## Assembly Instructions

### SPECIAL TIPS FOR FITTING CAM-LOCKS AND QUICKFIT

#### CAM-LOCK




WHEN FITTING CAMLOCK  
ENSURE STARTING POSITION IS CORRECT  
BEFORE YOU INSERT CONNECTING QUICKFIT  
TURN CLOCKWISE UNTIL SECURE



Quickfit head needs to be in centre

#### QUICKFIT

Tighten until shoulder is flush with panel. Do not overtighten or leave too loose. (see example below)



# TROMSO TALL BOY

## Item Code: 395662

### Assembly Instructions

**NOTE: Supplied wall plugs are only suitable for use in masonry walls.**

If you have any doubts about using the correct plug for your wall, please seek professional advice. Failure of the product due to using incorrect fixings is the responsibility of the installer.



#### IMPORTANT:

When drilling into walls, always check for hidden wires or pipes, etc.



### Tips & Tricks


**Make sure that the hardware used is suitable for supporting your unit.**

**Please consult a qualified tradesperson if unsure.**

- ☒ If you are unsure, please select a larger screw and wall plug.
- ☒ Ensure that you use the recommended drill bit to match the wall plug and hole size.
- ☒ Take extra care when drilling high walls, ceiling and ceramic tiles. Ensure wall plugs are inserted beyond the thickness of the ceramic tiles to avoid splitting or cracking.
- ☒ Ensure that wall plugs are well fitted and are a tight fit in the drilled hole.


### Types Of Walls

Use one of the following types of wall plug (not included) if your walls are made of brick, breeze block, concrete, stone or wood. Screws may be able to be fixed directly to solid wood walls as they will provide a secure anchor point.




#### 1. General Purpose Wall Plug

Generally, aerated blocks should not be used to support heavy loads, use a specialist fitting in this case. For light loads, general purpose wall plugs can be used.




#### 2. Plasterboard Wall Plug

For use when attaching light loads onto plasterboard partitions.




#### 3. Cavity Fixing Wall Plug

For use with plasterboard partitions or hollow wooden doors.




#### 4. Cavity Fixing Heavy Duty Wall Plug

For use when fitting or supporting heavy loads such as shelving and wall cabinets.



#### 5. Hammer Fixing Wall Plug

For use with concrete block or brick walls, or walls stuck with plasterboard. The hammer fixing allows it to be fixed to the wall rather than the plasterboard. Always check the fixing is secure to the retaining wall.



#### 6. Shield Anchor Wall Plug Heavy Loads


For use with concrete or brick walls, or for use with heavier loads such as TV & HiFi speakers and satellite dishes, etc.

# TROMSO TALL BOY


Item Code: 395662

## Assembly Instructions

### STEP 1




### STEP 2




# TROMSO TALL BOY

Item Code: 395662  
Assembly Instructions

## STEP 3



## STEP 4






# TROMSO TALL BOY


Item Code: 395662

## Assembly Instructions

### STEP 5



### STEP 6




# TROMSO TALL BOY


Item Code: 395662

## Assembly Instructions

### STEP 7



### STEP 8




# TROMSO TALL BOY


Item Code: 395662

## Assembly Instructions

### STEP 9



### STEP 10




# TROMSO TALL BOY

Item Code: 395662

## Assembly Instructions



### STEP 11



# TROMSO TALL BOY

Item Code: 395662  
Assembly Instructions

## STEP 12



**WARNING:** Anti-tipping hardware is only a deterrent. It is not a substitute for proper adult supervision. Young children may be injured by tipping furniture and the use of a tipping restraint is highly recommended. This hardware, when properly installed, could provide protection against the unexpected tipping of furniture due to improper use. Please ensure the anti-tipping hardware provided is suitable for your wall or else it might damage your wall during installation.

Domestic Use Only

B&M Retail, L24 8RJ, UK  
[www.bmstores.co.uk](http://www.bmstores.co.uk)  
B&M France SAS, 8 Rue du Bois Joli, 63800, France  
MADE IN CHINA

