



COBERG


UNDERSINK UNIT

ITEM CODE: 406480

Assembly Instructions


40min

APPROXIMATE ASSEMBLY TIME




2 PERSON ASSEMBLY

FLOOR AREA
1M x 1M




REQUIRED ASSEMBLY SPACE


REQUIRED ASSEMBLY TOOLS




SOFT RUBBER HAMMER(NOT PROVIDED)



SLOTTED SCREWDRIVER(NOT PROVIDED)



POZI SCREWDRIVER(NOT PROVIDED)




MEASURING TAPE(NOT PROVIDED)



ELECTRIC DRILL(NOT PROVIDED)

ASSEMBLED DIMENSIONS



Max. Loading: 19KG (CABINET: 10KG / SHELF: 3KG PER EACH)


COBERG UNDERSINK UNIT

Item Code: 406480

Assembly Instructions

NO.	PART LIST	QTY	NO.	PART LIST	QTY
①	TOP PANEL	1	⑥	RIGHT SIDE PANEL	1
②	LEFT SIDE PANEL	1	⑦	SHELF PANEL	2
③	DOOR	1	⑧	BOTTOM CROSS BAR	1
④	BACK PANEL	2	⑨	BOTTOM PANEL	1
⑤	MIDDLE PARTITION	1			

PART LIST













COBERG UNDERSINK UNIT





Item Code: 406480

Assembly Instructions

HARDWARE LIST

P1	x18	P2	x18	P3	x4	P4	x24	P5	x4
									
QUICKFIT		CAMLOCK		M4 x 35 mm SCREW		M5.8 x 30 mm WOOD DOWEL		M3.5 x 12 mm SCREW	

P6	x2	P7	x1	P8	x12	P9	x20	P10	x5
									
HINGE		PLASTIC CATCH		M4 x 12 mm SCREW		NAILS		ALLEN WRENCH	

P11	x2	P12	x2	P13	x2	P14	x1
							
M5 x 12 mm SCREW		ANTI-TIPPING METAL PLATE		WALL PLUG		METAL HANDLE	

COBERG UNDERSINK UNIT

Item Code: 406480

Assembly Instructions



Safety Advice and Care Advice

KEEP ALL THE SAFETY ADVICE AND INSTRUCTIONS IN A SAFE PLACE FOR FUTURE REFERENCE!



WARNING! RISK OF LOSS OF LIFE OR ACCIDENT

TO INFANTS AND CHILDREN! Never leave children unsupervised with the packaging materials. Danger of suffocation.



CAUTION! RISK OF INJURY! Make sure that all parts are undamaged and assembled correctly. Improper assembly carries a risk of injury. Damaged parts may affect the safety and function of the product.

- Adult assembly required.
- Power tools are not recommended for the assembly of this product.
- Make sure that this product is stable & used only on a solid & flat surface.
- Do not use this product unless all screws and fixings are firmly secured.
- Do not leave children unsupervised! The product is not a climbing frame or a toy!
- Do not stand, sit or lean on this product.
- Do not use this product as a step ladder or as a chopping surface.
- Do not lift or move the product when it is loaded.
- Do not load more than a total of 19kg (Cabinet: 10kg/Shelf: 3kg per each) onto the unit, otherwise there is a risk of injury and/or damage to the product.
- Distribute weight evenly across the product so that it cannot overturn.
- Do not place hot items such as coffee cups directly on the surface(s) unless adequately thick table mats are used.
- Please periodically check all fittings and re-tighten as necessary.
- For Indoor & Domestic use only.

Care instructions:

- Wipe clean with a dry cloth.
- Do not use scourers, abrasive or chemical solvents.
- Keep away from moisture and direct sunlight.
- Keep away from fire and inflammable objects.
- Store in a dry place.


COBERG UNDERSINK UNIT

Item Code: 406480



Assembly Instructions

SPECIAL TIPS FOR FITTING CAM-LOCKS AND QUICKFIT

CAM-LOCK




WHEN FITTING CAMLOCK
ENSURE STARTING POSITION IS CORRECT
BEFORE YOU INSERT CONNECTING QUICKFIT
TURN CLOCKWISE UNTIL SECURE



Quickfit head needs to be in centre

QUICKFIT

Tighten until shoulder is flush with panel. Do not overtighten or undertighten (see example below)



COBERG UNDERSINK UNIT

Item Code: 406480

Assembly Instructions

NOTE: Supplied wall plugs are only suitable for use in masonry walls.

If you have any doubts about using the correct plug for your wall, please seek professional advice. Failure of the product due to using incorrect fixings is the responsibility of the installer.



IMPORTANT:

When drilling into walls, always check for hidden wires or pipes, etc.



Tips & Tricks


Make sure that the hardware used is suitable for supporting your unit.

Please consult a qualified tradesperson if unsure.

- ✓ If you are unsure, please select a larger screw and wall plug.
- ✓ Ensure that you use the recommended drill bit to match the wall plug and hole size.
- ✓ Take extra care when drilling high walls, ceiling and ceramic tiles. Ensure wall plugs are inserted beyond the thickness of the ceramic tiles to avoid splitting or cracking.
- ✓ Ensure that wall plugs are well fitted and are a tight fit in the drilled hole.


Types Of Walls

Use one of the following types of wall plug (not included) if your walls are made of brick, breeze block, concrete, stone or wood. Screws may be able to be fixed directly to solid wood walls as they will provide a secure anchor point.




1. General Purpose Wall Plug

Generally, aerated blocks should not be used to support heavy loads, use a specialist fitting in this case. For light loads, general purpose wall plugs can be used.




2. Plasterboard Wall Plug

For use when attaching light loads onto plasterboard partitions.




3. Cavity Fixing Wall Plug

For use with plasterboard partitions or hollow wooden doors.




4. Cavity Fixing Heavy Duty Wall Plug

For use when fitting or supporting heavy loads such as shelving and wall cabinets.



5. Hammer Fixing Wall Plug

For use with concrete block or brick walls, or walls stuck with plasterboard. The hammer fixing allows it to be fixed to the wall rather than the plasterboard. Always check the fixing is secure to the retaining wall.



6. Shield Anchor Wall Plug Heavy Loads


For use with concrete or brick walls, or for use with heavier loads such as TV & HiFi speakers and satellite dishes, etc.

COBERG UNDERSINK UNIT


Item Code: 406480

Assembly Instructions

STEP 1



P1 x 18




COBERG UNDERSINK UNIT

Item Code: 406480

Assembly Instructions

STEP 2




P3 x 2



P4 x 2

STEP 3



P2 x 4



P4 x 4

COBERG UNDERSINK UNIT

Item Code: 406480

Assembly Instructions


STEP 4



P2 x 8



P4 x 12




COBERG UNDERSINK UNIT

Item Code: 406480

Assembly Instructions

STEP 5



P5 x 2



P7 x 1




P11 x 2



P12 x 2

STEP 6



P2 x 6




P4 x 6

COBERG UNDERSINK UNIT

Item Code: 406480


Assembly Instructions

STEP 7




P9 x 20

STEP 8



P5 x 2



P6 x 2



P8 x 4





P14 x 1

COBERG UNDERSINK UNIT

Item Code: 406480

Assembly Instructions

STEP 9




IMPORTANT: IF DOOR NOT ALIGNED

Screw A: You can adjust the doors up and down by releasing screw A.

Screw B: Release Screw B you can move the door forward or back till it is in the right position, then fully screw them.

Screw C: You can adjust the gap between the door and the side board by turning Screw C clockwise or anti-clockwise.

STEP 10












COBERG UNDERSINK UNIT

Item Code: 406480

Assembly Instructions

STEP 12



WARNING: Anti-tipping hardware is only a deterrent. It is not a substitute for proper adult supervision. Young children may be injured by tipping furniture and the use of a tipping restraint is highly recommended.

This hardware, when properly installed, could provide protection against the unexpected tipping of furniture due to improper use. Please ensure the anti-tipping hardware provided is suitable for your wall or else it might damage your wall during installation.

Domestic use only



B&M Retail, L24 8RJ, UK
www.bmstores.co.uk
Homesavers, 5 Old Dublin Rd, Dublin, A94 K1H5
MADE IN CHINA