

EVEREADY®

CORDLESS UTILITY LIGHT

User Manual

Mounting Instructions:

- Choose a suitable location where there is light required.
- This product comes complete with double sided adhesive tape.
- This light is suitable for indoor and outdoor use. When using outdoors, please install in a sheltered location.
- Before mounting with the double sided adhesive tape please make sure that the surface is clean and dry.
- For good and firm grip please press and hold the light for at least 30 seconds as shown in FIG. A. Permanent bond will be formed within 24 hours.
- For mounting with screws, remove the base plate by removing the central screw with an appropriate screwdriver (not included) as shown in FIG. B. This will allow you to use it as a template to mark the positions of the screws.
- Once fitted, you can rotate and pivot the light to the required angle as shown in FIG. C.
- When using this light outdoor please only mount in sheltered locations. Please keep motion sensor clean for better performance and keep checking the batteries.



FIG A.



FIG B.



FIG C.

Warnings:

- When using this light outdoor please mount in sheltered locations.
- Please keep motion sensor clean for better performance and keep checking the batteries.
- Wipe with damp cloth only.
- While mounting in high positions, please use a safe and sturdy ladder remembering to choose a location that will allow you easy access to replace the batteries.