DESK FAN

ASSEMBLY GUIDE

ASSEMBLING THE DESK FAN






STEP 1: Remove the washer and screw from the base pole.



STEP 2: Install the base pole with the washer and base-locking screw.




STEP 3: Remove the four grill-locking screws from the motor assembly unit.



STEP 4: Install the rear grill with the handle at the top and facing out towards the motor assembly unit using the four grill-locking screws.



STEP 5: Remove the rubber part from the motor shaft and turn the groove of the motor shaft upwards.



STEP 6: Slide the fan blade unit onto the motor shaft, aligning and tightening the fan blade screw to the groove.



STEP 7: Hook the front grill onto the rear grill, aligning both screw holes at the bottom of each grill.



STEP 8: Install the grill screw and nut to lock the guards. Close the clips.



STEP 9: Plug in the fan. Unplug after use.

Note: Take care not to overtighten the base locking screw as this could cause damage to the base. Do not use tools to tighten the base-locking screw; the base should be attached firmly so that when the fan is fully assembled, the adjustable base pole and motor assembly do not wobble whilst the base remains flat.


USING THE DESK FAN



STEP 1: To adjust tilting angle, loosen the head tilt screw. Tighten again at the desired tilt.



STEP 2: To switch the fan on, select speeds I-III on the adjustable cooling speed dial. To switch fan off, select 0.



STEP 3: Push the oscillation switch down to activate oscillation function. Pull the oscillation switch up for normal operation.

Caution: Do not cover the fan head.





DO NOT PRINT THIS PAGE ARTWORK REFERENCE ONLY