



NORSK 3 DRAWER CHEST


ITEM CODE: 388961

Assembly Instruction

1.0hr

APPROXIMATE ASSEMBLY TIME

2 PEOPLE ASSEMBLY




FLOOR AREA
1Mx1M




REQUIRED ASSEMBLY SPACE


REQUIRED ASSEMBLY TOOLS




SOFT RUBBER HAMMER(Not Provided)



SLOTTED SCREWDRIVER(Not Provided)




POZI SCREWDRIVER(Not Provided)



MEASURING TAPE (Not Provided)


ASSEMBLED DIMENSIONS



**MODEL NAME:
NORSK 3 DRAWER CHEST
388961**



NO.	PART LIST	QTY	NO.	PART LIST	QTY
(1)	LEFT DRAWER SIDE PANEL	3	(8)	FRONT CROSS BAR	3
(2)	RIGHT DRAWER SIDE PANEL	3	(9)	MIDDLE CROSS BAR	4
(3)	BACK DRAWER PANEL	3	(10)	DRAWER BOTTOM SUPPORT BAR	3
(4)	BOTTOM DRAWER PANEL	3	(11)	TOP PANEL	1
(5)	DRAWER FRONT PANEL	3	(12)	BACK PANEL	2
(6)	LEFT SIDE PANEL	1	(13)		
(7)	RIGHT SIDE PANEL	1	(14)		


PART LIST




**MODEL NAME:
NORSK 3 DRAWER CHEST
388961**

HARDWARE LIST

P1	x19	P2	x19	P3	x20	P4	x16	P5	x38
					Dia.4x35mm		Dia.8x30mm		Dia.3.5x12mm
Male camlock		Female camlock		Screw		Dowel		Screw	

P6	x3	P7	x2	P8	x2	P9	x4	P10	x1
 CL DL DR CR									
Drawer runner		Wall strap		Wall plug		support plate		Back panel joint strip	

P11	x18	P12	x1	P13	x4	P14	x16	P15	x16
							Dia.5x40mm		
Nails		Allen key		Protective feet		Screw		Screw head cover	

**MODEL NAME:
NORSK 3 DRAWER CHEST
388961**



Safety Advice and Care Advice

KEEP ALL THE SAFETY ADVICE AND INSTRUCTIONS IN A SAFE PLACE FOR FUTURE REFERENCE!

⚠ WARNING! RISK OF LOSS OF LIFE OR ACCIDENT TO INFANTS AND CHILDREN! Never leave children unsupervised with the packaging materials. Danger of suffocation.

⚠ CAUTION! RISK OF INJURY! Make sure that all parts are undamaged and assembled correctly. Improper assembly carries a risk of injury. Damaged parts may affect the safety and function of the product.

- Make sure that this product is standing on a solid, level surface.
- ⚠ CAUTION!** Do not leave children unsupervised! The product is not a climbing frame or a toy! Make sure that nobody, especially a child, climbs on or leans against the product.
- Distribute weight evenly across the product so that it cannot overturn.
- Do not load more than a total of 30kg onto the product, otherwise there is a risk of injury and/or damage to the product.
- Check that the product is stable before using it.
- Do not lift or move the product when it is loaded.
- Keep away from fire and inflammable objects.
- **Wipe clean with a damp cloth.**
- Make sure that all screws and fixings are secure before use.
- Do not place very hot or very cold items on the surface(s) unless adequately thick table mats are used.
- Please periodically check all fittings and re-tighten as necessary.
- Domestic use only.

MODEL NAME: NORSK 3 DRAWER CHEST 388961

NOTE: Supplied wall plugs are only suitable for use in masonry walls.

If you have any doubts about using the correct plug for your wall, please seek professional advice. Failure of the product due to using incorrect fixings is the responsibility of the installer.



IMPORTANT:

When drilling into walls, always check for hidden wires or pipes, etc.




Tips & Tricks

**Make sure that the hardware used is suitable for supporting your unit.
Please consult a qualified tradesperson if unsure.**

- ✓ If you are unsure, please select a larger screw and wall plug.
- ✓ Ensure that you use the recommended drill bit to match the wall plug and hole size.
- ✓ Take extra care when drilling high walls, ceiling and ceramic tiles. Ensure wall plugs are inserted beyond the thickness of the ceramic tiles to avoid splitting or cracking.
- ✓ Ensure that wall plugs are well fitted and are a tight fit in the drilled hole.


Types Of Walls

Use one of the following types of wall plug (not included) if your walls are made of brick, breeze block, concrete, stone or wood. Screws may be able to be fixed directly to solid wood walls as they will provide a secure anchor point.




1. General Purpose Wall Plug

Generally, aerated blocks should not be used to support heavy loads, use a specialist fitting in this case. For light loads, general purpose wall plugs can be used.




2. Plasterboard Wall Plug

For use when attaching light loads onto plasterboard partitions.




3. Cavity Fixing Wall Plug

For use with plasterboard partitions or hollow wooden doors.




4. Cavity Fixing Heavy Duty Wall Plug

For use when fitting or supporting heavy loads such as shelving and wall cabinets.



5. Hammer Fixing Wall Plug

For use with concrete block or brick walls, or walls stuck with plasterboard. The hammer fixing allows it to be fixed to the wall rather than the plasterboard. Always check the fixing is secure to the retaining wall.





6. Shield Anchor Wall Plug Heavy Loads

For use with concrete or brick walls, or for use with heavier loads such as TV & HiFi speakers and satellite dishes, etc.

**MODEL NAME:
NORSK 3 DRAWER CHEST
388961**


**SPECIAL TIPS FOR FITTING CAM-LOCKS
AND QUICKFIT**



Quickfit head needs to be in centre


QUICKFIT

Tighten until shoulder is flush with panel. Do not overtighten or undertighten (see example below)




**MODEL NAME:
NORSK 3 DRAWER CHEST
388961**

STEP 1




STEP 2




**MODEL NAME:
NORSK 3 DRAWER CHEST
388961**

STEP 3




STEP 4




MODEL NAME: NORSK 3 DRAWER CHEST 388961

STEP 5




STEP 6




**MODEL NAME:
NORSK 3 DRAWER CHEST
388961**

STEP 7




STEP 8




MODEL NAME: NORSK 3 DRAWER CHEST 388961

STEP 9




STEP 10



WARNING: Anti-tipping hardware is only a deterrent. It is not a substitute for proper adult supervision. Young children can be injured by tipping furniture and the use of a tipping restraint is highly recommended. This hardware, when properly installed, could provide protection against the unexpected tipping of furniture due to improper use.

Please ensure the anti-tipping hardware provided is suitable for your wall or else, it might damage your wall during installation.

Peel off the PVC protective mask before using



Guarantee

This product is guaranteed for twelve months from the date of original purchase. If any defect should occur due to faulty materials or workmanship, the unit will either be replaced or refunded at our discretion.

You will need to have your receipt or proof of purchase.

The following conditions apply:

- The product must be returned to the retailer with original proof of purchase.
- It is only valid in the UK.
- It does not cover wear and tear, damage, misuse or consumable parts.
- The product must be correctly installed and operated in accordance with the instructions contained in the instruction manual.
- The product must be used solely for domestic purposes.
- The guarantee will be rendered invalid if the product is re-sold or has been damaged by inexpert repair.
- The guarantee is in addition to, and does not diminish your statutory or legal rights.

Manufactured by
B&M Retail Ltd
L24 8RJ, UK

Made in China