



1 DRAWER BEDSIDE CHEST

ITEM CODE: 389074 Assembly Instructions


30 MINS




FLOOR AREA 1Mx1M

APPROXIMATE ASSEMBLY TIME 1 PERSON ASSEMBLY

REQUIRED ASSEMBLY SPACE







ASSEMBLED DIMENSIONS


32cm 32cm (approx.) (approx.) 48cm (approx.)

MAX. LOADING: 5KG (TOP: 3KG / DRAWER: 2KG)

ITEM CODE: 389074
Assembly Instructions

NO.	PART LIST	QTY	NO.	PART LIST	QTY
(1)	TOP PANEL	1	(6)	DRAWER BACK PANEL	1
(2)	LEFT SIDE PANEL	1	(7)	DRAWER SIDE PANEL	1
(3)	RIGHT SIDE PANEL	1	(8)	DRAWER BOTTOM PANEL	1
(4)	BOTTOM SHELF	1	(9)	DRAWER FRONT PANEL	1
(5)	BACK PANEL	1	(10)	DRAWER SIDE PANEL	1

PART LIST



ITEM CODE: 389074
Assembly Instructions

HARDWARE LIST

Α	x4	В	x12	С	x12	D	x2	E	x1	
A THE THE PARTY OF						Dimension				
Dia.4x30mm				Dia.4x35mm		Dia.4x20mm				
SCREW			CAM LOCK	SCREW		SCREW		HANDLE		
F	x4	G	x2	Н	x8	ı	x8	J	x2	
	Spinite.	\$							Ø	
	Dia.3x10mm						Dia.2x21mm		Dia.12x11mm	
SCREW		D	RAWER RAIL	DOWEL		SCREW		PIN		

ITEM CODE: 389074
Assembly Instructions



Safety Advice and Care Advice

KEEP ALL THE SAFETY ADVICE AND INSTRUCTIONS IN A SAFE PLACE FOR FUTURE REFERENCE!

↑ WARNING! RISK OF LOSS OF LIFE OR ACCIDENT

TO INFANTS AND CHILDREN! Never leave children unsupervised with the packaging materials. Danger of suffocation.

⚠ CAUTION! RISK OF INJURY! Make sure that all parts are undamaged and assembled correctly. Improper assembly carries a risk of injury. Damaged parts may affect the safety and function of the product.

- · Adult assembly required.
- Power tools are not recommended for this product.
- Make sure that this product is stable & used only on a solid & flat surface.
- · Do not use this product unless all screws and fixings are firmly secured.
- Do not leave children unsupervised! The product is not a climbing frame or a toy!
- · Do not stand, sit or lean on this product
- Do not use this product as a step ladder or as a chopping surface.
- Do not lift or move the product when it is loaded.
- Do not load more than a total of 5kg (Top: 3kg/Drawer: 2kg), otherwise there is a risk of injury and/or damage to the product.
- Distribute weight evenly across the product so that it cannot overturn.
- Do not place hot items such as coffee cups directly on the surface(s) unless adequately thick table mats are used.
- · Please periodically check all fittings and re-tighten as necessary.
- For Indoor & Domestic use only.


Care instructions:


- · Wipe clean with a dry cloth.
- · Do not use scourers, abrasive or chemical solvents.
- Keep away from moisture and direct sunlight.
- · Keep away from fire and inflammable objects.
- Store in a dry place.

ITEM CODE: 389074
Assembly Instructions

SPECIAL TIPS FOR FITTING CAM-LOCKS AND QUICKFIT









Quickfit head needs to be in centre

QUICKFIT Tighten until shoulder is fiush with panel. Do not overtinghten or undertinghten(see example below) Shoulder Panel


ITEM CODE: 389074
Assembly Instructions






ITEM CODE: 389074
Assembly Instructions

STEP 3




STEP 4




ITEM CODE: 389074
Assembly Instructions






STEP 6



ITEM CODE: 389074
Assembly Instructions





STEP 8

