



HIGH GLOSS UNDERSINK UNIT

ITEM CODE: 395548
Assembly Instructions

1.0hr


770

2 PERSON ASSEMBLY

FLOOR AREA 1.5Mx1.5M


REQUIRED ASSEMBLY SPACE

APPROXIMATE ASSEMBLY TIME
REQUIRED ASSEMBLY TOOLS





ASSEMBLED DIMENSIONS




Max. Loading: 20kg

NÖRSK HIGH GLOSS UNDERSINK UNIT

ITEM CODE: 395548

NO	PART LIST	QTY	NO	PART LIST	QTY
1	TOP PANEL	1	7	BOTTOM PANEL	1
2	LEFT SIDE PANEL	1	8	BOTTOM SUPPORT	1
3	RIGHT SIDE PANEL	1	9	BOTTOM SUPORT PANEL	1
4	DOOR	2	10	FRONT PANEL	1
5	BACK PANEL	2	11)	SUPPORT PANEL	1
6	SHELF PANEL	1	12	TOP SUPPORT	1

PARTS LIST




NÖRSK HIGH GLOSS UNDERSINK UNIT

ITEM CODE: 395548

HARDWARE LIST

а		x24	b)	x24	С		x24	d		х3	е		x16
		_	0	A N A L O O L C	,	\A(0)		\ A / E I		//4x25m			13.5x12	
QUICKFIT		C	AMLOCK	`	VVO	OD DO	vv⊨L		SCREW			SCREW	′	



NÖRSK HIGH GLOSS UNDERSINK UNIT

ITEM CODE: 395548



Safety Advice and Care Advice

KEEP ALL THE SAFETY ADVICE AND INSTRUCTIONS IN A SAFE PLACE FOR FUTURE REFERENCE!

MARNING! RISK OF LOSS OF LIFE OR ACCIDENT

TO INFANTS AND CHILDREN! Never leave children unsupervised with the packaging materials. Danger of suffocation.

⚠ CAUTION! RISK OF INJURY! Make sure that all parts are undamaged and assembled correctly. Improper assembly carries a risk of injury. Damaged parts may affect the safety and function of the product.

- · Adult assembly required.
- Power tools are not recommended for this product.
- Make sure that this product is stable & used only on a solid & flat surface.
- Do not use this product unless all screws and fixings are secure firmly secured.
- Do not leave children unsupervised! The product is not a climbing frame or a toy!
- Do not stand, sit or lean on this product
- Do not use this product as a step ladder or as a chopping surface.
- Do not lift or move the product when it is loaded.
- Do not load more than a total of 20kg onto the unit, otherwise there is a risk of injury and/or damage to the product
- Distribute weight evenly across the product so that it cannot overturn.
- Do not place hot items such as coffee cups directly on the surface(s) unless adequately thick table mats are used.
- · Please periodically check all fittings and re-tighten as necessary.
- For Indoor & Domestic use only.

Care instructions:


- Wipe clean with a dry cloth.
- Do not use scourers, abrasive or chemical solvents.
- · Keep away from moisture and direct sunlight.
- Keep away from fire and inflammable objects.


NÖRSK HIGH GLOSS UNDERSINK UNIT

ITEM CODE: 395548


SPECIAL TIPS FOR FITTING CAM-LOCKS AND QUICKFIT

CAM-LOCK





Quickfit head needs to be in centre




NÖRSK HIGH GLOSS UNDERSINK UNIT

ITEM CODE: 395548

CAUTION: Please peel off the PVC mask before the assembly.
















NÖRSK HIGH GLOSS UNDERSINK UNIT

ITEM CODE: 395548






NÖRSK HIGH GLOSS UNDERSINK UNIT

ITEM CODE: 395548


















NÖRSK HIGH GLOSS UNDERSINK UNIT

ITEM CODE: 395548






NÖRSK HIGH GLOSS UNDERSINK UNIT


ITEM CODE: 395548







STEP10









NÖRSK HIGH GLOSS UNDERSINK UNIT

ITEM CODE: 395548






IMPORTANT: IF DOOR NOT ALIGNED

- Screw A: You can adjust the doors up and down by releasing screw A.
- Screw B: Release Screw B you can move the door forward or back till it is in the right position, then fully screw them.
- Screw C: You can adjust the gap between the door and the side board by turning Screw C clockwise or anti-clockwise.


NÖRSK HIGH GLOSS UNDERSINK UNIT

ITEM CODE: 395548





STEP 13



NÖRSK HIGH GLOSS UNDERSINK UNIT

ITEM CODE: 395548

Guarantee

This product is guaranteed for twelve months from the date of original purchase. If any defect should occur due to faulty materials or workmanship, the unit will either be replaced or refunded at our discretion.

You will need to have your receipt or proof of purchase.

The following conditions apply:

- The product must be returned to the retailer with original proof of purchase.
- It is only valid in the UK.
- It does not cover wear and tear, damage, misuse or consumable parts.
- The product must be correctly installed and operated in accordance with the instructions contained in the instruction manual.
- The product must be used solely for domestic purposes.
- The guarantee will be rendered invalid if the product is re-sold or has been damaged by inexpert repair.
- The guarantee is in addition to, and does not diminish your statutory or legal rights.



Made in China