

AXEL COFFEE TABLE 407744

1.0hr





FLOOR AREA 2.0M X 2.0M


REQUIRED ASSEMBLY SPACE

APPROXIMATE ASSEMBLY TIME 1 PERSON ASSEMBLY

REQUIRED ASSEMBLY TOOLS








SOFT RUBBER HAMMER (Not Provided)

POZI SCREWDRIVER (Not Provided)


SLOTTED SCREWDRIVER (Not Provided)




AXEL COFFEE TABLE 407744

NO.	PART LIST	QTY	NO.	PART LIST	QTY
(1)	TOP PANEL	1	(7)	BOTTOM PANEL	1
(2)	RIGHT SIDE PANEL	1			
(3)	LEFT SIDE PANEL	1			
(4)	BACK SUPPORT PANEL	1			
(5)	MIDDLE PANEL	1			
(6)	DOOR	1			

PARTS LIST



AXEL COFFEE TABLE 407744



PARTICLE

AXEL COFFEE TABLE 407744

Top Tips before you start!

- 1. Please check that all parts are present before you start the assembly of your furniture.
- **2.** For ease and speed of assembly, we recommend that before you commence each step of the assembly, that you identify all the parts required for that step.
- **3.** For larger items, please ensure that you have sufficient space and people (as indicated on page 1) to assemble your product safely
- **4.** We recommend that, where possible, all items are assembled near to the area in which they will be placed in use, to avoid moving the product unnecessarily once assembled.
- **5.** For the protection of your furniture, we recommend that the product is placed on a protected surface during assembly to prevent any damage.
- **6.** During assembly please take care not to over-tighten any fittings, as this may damage the product.
- **7.** Always place the product on a flat, steady and stable surface.
- **8.** Do not sit or stand on the product. Do not use the product as a stepladder.
- **9.** This product is intended for indoor, household use only as it is non industrial product.
- **10.** Please do not kneel on any part of this product during assembly.
- **11.** Do not load more than a total of 20kgs onto the product, otherwise there is a risk of injury and/or damage to the product.
- **12.** Make sure the product is stable and distribute weight evenly across it so that it cannot overturn.

Care and Maintenance of your Furniture

- Please periodically check all fittings and re-tighten as necessary.
- To clean your item, please use a damp cloth and wipe clean.
- Never allow any kind of liquid to remain on your furniture. Absorption can cause wood to warp or finishes to de-laminate.
- Please do not place hot items (e.g. hot drinks) directly on to the wood surface.
- Please do not drag and pull your furniture.

AXEL COFFEE TABLE 407744

SPECIAL TIPS FOR FITTING CAM-LOCKS **AND QUICKFIT**

CAM-LOCK



WHEN FITTING CAMLOCK ENSURE STARTING POSITION IS CORRECT BEFORE YOU INSERT CONNECTING QUICKFIT TURN CLOCKWISE UNTIL SECURE



CORRECT















Quickfit head needs to be in centre

DRAWER **CAM-LOCK**






QUICKFIT


Tighten until shoulder is flush with panel. Do not overtighten or undertighten (see example









Panel







AXEL COFFEE TABLE 407744










AXEL COFFEE TABLE 407744


STEP 7



E spcs

4pcs

STEP 8



9/10

AXEL COFFEE TABLE 407744

