



3 TIER MULTI PURPOSE TROLLEY - SAGE

SPACEWAYS

ITEM CODE: 417087
Assembly Instructions

45 min

APPROXIMATE ASSEMBLY TIME

1 PERSON ASSEMBLY




FLOOR AREA
1 X 1M



REQUIRED ASSEMBLY SPACE

ASSEMBLED DIMENSIONS



Max. Loading: 12kg (4kg per shelf)


SPACEWAY 3 TIER MULTI PURPOSE TROLLEY - SAGE

ITEM CODE: 417087

Assembly Instructions

NO	PART LIST	QTY	NO	PART LIST	QTY
①	PLASTIC TRAY	3	④	BOTTOM CONNECTION PIPE	2
②	CONNECTION PIPE	8	⑤	CASTOR WHEEL WITH BRAKE	2
③	TOP HANDLE	1	⑥	CASTOR WHEEL	2

PARTS LIST





SPACEWAY 3 TIER MULTI PURPOSE TROLLEY - SAGE

ITEM CODE: 417087

Assembly Instructions

HARDWARE LIST

A	x12	B	x2	C	x1
					

SPACEWAY 3 TIER MULTI PURPOSE TROLLEY - SAGE

ITEM CODE: 417087

Assembly Instructions



Safety Advice and Care Advice

KEEP ALL THE SAFETY ADVICE AND INSTRUCTIONS IN A SAFE PLACE FOR FUTURE REFERENCE!



WARNING! RISK OF LOSS OF LIFE OR ACCIDENT

TO INFANTS AND CHILDREN! Never leave children unsupervised with the packaging materials. Danger of suffocation.



CAUTION! RISK OF INJURY! Make sure that all parts are undamaged and assembled correctly. Improper assembly carries a risk of injury. Damaged parts may affect the safety and function of the product.

- Adult assembly required.
- Power tools are not recommended for the assembly of this product.
- Make sure that this product is stable & used only on a solid & flat surface.
- Do not use this product unless all screws and fixings are firmly secured.
- Do not leave children unsupervised! The product is not a climbing frame or a toy!
- Do not stand, sit or lean on this product.
- Do not use this product as a step ladder or as a chopping surface.
- Do not lift or move the product when it is loaded.
- Do not load more than a total of 12kg (4kg per shelf) onto the unit, otherwise there is a risk of injury and/or damage to the product.
- Distribute weight evenly across the product so that it cannot overturn.
- Do not place hot items such as coffee cups directly on the surface(s) unless adequately thick table mats are used.
- Please periodically check all fittings and re-tighten as necessary.
- For Indoor & Domestic use only.

Care instructions:


- Wipe clean with a dry cloth.
- Do not use scourers, abrasive or chemical solvents.
- Keep away from moisture and direct sunlight.
- Keep away from fire and inflammable objects.
- Store in a dry place.

SPACEWAY 3 TIER MULTI PURPOSE TROLLEY - SAGE


ITEM CODE: 417087

Assembly Instructions

STEP 1



STEP 2



A x 4




C x 1

SPACEWAY 3 TIER MULTI PURPOSE TROLLEY - SAGE

ITEM CODE: 417087

Assembly Instructions

STEP 3




A x 4



C x 1

STEP 4



A x 4



B x 2




C x 1

SPACEWAY 3 TIER MULTI PURPOSE TROLLEY - SAGE

ITEM CODE: 417087

Assembly Instructions

STEP 5



B&M Retail, L24 8RJ, UK

www.bmstores.co.uk

B&M France SAS, 8 Rue du Bois Joli, 63800, France

MADE IN CHINA

Domestic use only