

home essentials

7 TIER SHOE RACK

ITEM CODE: 417844
Assembly Instructions

A) x 2 B) x 4 C) x 8 D) x 14

ASSEMBLED DIMENSIONS



CAUTION! Do not leave children unsupervised!

The product is not a climbing frame or a toy!

Make sure that this product is standing on a solid, level surface.

Make sure that no body, especially a child, climbs on or leans against the product.


Distribute weight upon this product's surface evenly so that it cannot overturn.

Check that the product is stable before using it.

Do not lift the product and do not move it when it is loaded.

Make sure that all fixings are secure before use.

Care and Cleaning: Wipe clean with a damp cloth.



Domestic use only MAX. LOADING: 14KG (2KG EACH)

