



LISBON

TV UNIT

Item Code: 418369

Assembly Instructions


1hr

APPROXIMATE ASSEMBLY TIME

2 PEOPLE ASSEMBLY




FLOOR AREA
2Mx2M




REQUIRED ASSEMBLY SPACE


REQUIRED ASSEMBLY TOOLS



SOFT RUBBER HAMMER (Not Provided)




POZI SCREWDRIVER (Not Provided)



MEASURING TAPE (Not Provided)

ASSEMBLED DIMENSIONS



MAX LOADING: 40KG (TOP: 20KG, SHELF: 5KG EACH)


LISBON TV UNIT

Item Code: 418369

Assembly Instructions

| NO. | PART LIST | QTY | NO. | PART LIST | QTY |
|-----|-------------------------|-----|-----|------------------|-----|
| ① | TOP PANEL | 1 | ⑦ | SHELF PANEL | 1 |
| ② | LEFT SIDE PANEL | 1 | ⑧ | BOTTOM PANEL | 1 |
| ③ | LEFT SIDE MIDDLE PANEL | 1 | ⑨ | LEFT DOOR PANEL | 1 |
| ④ | RIGHT SIDE MIDDLE PANEL | 1 | ⑩ | BOTTOM BAR | 1 |
| ⑤ | RIGHT SIDE PANEL | 1 | ⑪ | BOTTOM BAR | 2 |
| ⑥ | BACK PANEL | 1 | ⑫ | RIGHT DOOR PANEL | 1 |

PART LIST






LISBON TV UNIT

Item Code: 418369

Assembly Instructions

HARDWARE LIST

| | | | | | | | | | |
|---|-----|---|-----|---|-----|--|-----|--|----|
| P1 | x18 | P2 | x18 | P3 | x24 | P4 | x22 | P5 | x4 |
|  | |  | |  | |  | |  | |
| M6 x 35mm | | M15 x 10mm | | M4 x 12mm | | M8 x 30mm | | M3.5 x 12mm | |
| QUICKFIT | | CAM-LOCK | | SCREW | | WOOD DOWEL | | SCREW | |
| P6 | x2 | P7 | x12 | P8 | x2 | P9 | x1 | P10 | x4 |
|  | |  | |  | |  | |  | |
| | | M5 x 40mm | | | | | | M4 x 18mm | |
| PLASTIC CATCH | | SCREW | | HANDLE | | ALLEN WRENCH | | SCREW | |
| P11 | x6 | P12 | x4 | P13 | x18 | | | | |
|  | |  | |  | | | | | |
| 15mm | | | | | | | | | |
| FLOOR PROTECTOR | | METAL HINGE | | STICKER | | | | | |

LISBON TV UNIT

Item Code: 418369

Assembly Instructions



Safety Advice and Care Advice

KEEP ALL THE SAFETY ADVICE AND INSTRUCTIONS IN A SAFE PLACE FOR FUTURE REFERENCE!

⚠️ WARNING! RISK OF LOSS OF LIFE OR ACCIDENT

TO INFANTS AND CHILDREN! Never leave children unsupervised with the packaging materials. Danger of suffocation.

⚠️ CAUTION! RISK OF INJURY! Make sure that all parts are undamaged and assembled correctly. Improper assembly carries a risk of injury. Damaged parts may affect the safety and function of the product.

- Adult assembly required.
- Power tools are not recommended for the assembly of this product.
- Make sure that this product is stable & used only on a solid & flat surface.
- Do not use this product unless all screws and fixings are firmly secured.
- Do not leave children unsupervised! The product is not a climbing frame or a toy!
- Do not stand, sit or lean on this product.
- Do not use this product as a step ladder or as a chopping surface.
- Do not lift or move the product when it is loaded.
- Do not load more than a total of 40kg (Top: 20kg, Shelf: 5kg each) onto the unit, otherwise there is a risk of injury and/or damage to the product.
- Distribute weight evenly across the product so that it cannot overturn.
- Do not place hot items such as coffee cups directly on the surface(s) unless adequately thick table mats are used.
- Please periodically check all fittings and re-tighten as necessary.
- For Indoor & Domestic use only.

Care instructions:

- Wipe clean with a dry cloth.
- Do not use scourers, abrasive or chemical solvents.
- Keep away from moisture and direct sunlight.
- Keep away from fire and inflammable objects.
- Store in a dry place.

LISBON TV UNIT

Item Code: 418369



Assembly Instructions

SPECIAL TIPS FOR FITTING CAM-LOCKS AND QUICKFIT

CAM-LOCK




WHEN FITTING CAMLOCK
ENSURE STARTING POSITION IS CORRECT
BEFORE YOU INSERT CONNECTING QUICKFIT
TURN CLOCKWISE UNTIL SECURE



Quickfit head needs to be in centre

QUICKFIT

Tighten until shoulder is flush with panel. Do not overtighten or leave too loose. (see example below)




LISBON TV UNIT


Item Code: 418369

Assembly Instructions

STEP 1



STEP 2




LISBON TV UNIT


Item Code: 418369

Assembly Instructions

STEP 3



STEP 4




LISBON TV UNIT


Item Code: 418369

Assembly Instructions

STEP 5



STEP 6





LISBON TV UNIT



Item Code: 418369

Assembly Instructions

STEP 7



STEP 8




LISBON TV UNIT


Item Code: 418369

Assembly Instructions

STEP 9



STEP 10





LISBON TV UNIT

Item Code: 418369

Assembly Instructions

STEP 11



IMPORTANT: IF DOOR NOT ALIGNED

Screw A: You can adjust the doors up and down by releasing screw A.

Screw B: Release Screw B you can move the door forward or back till it is in the right position, then fully screw them.

Screw C: You can adjust the gap between the door and the side board by turning Screw C clockwise or anti-clockwise.




P3 x 16

LISBON TV UNIT

Item Code: 418369

Assembly Instructions

STEP 12



Domestic Use Only

B&M Retail, L24 8RJ, UK
www.bmstores.co.uk
B&M France SAS, 8 Rue du Bois Joli, 63800, France
MADE IN CHINA

