



# **COFFEE TABLE**

ITEM CODE: 418408
Assembly Instructions

1hr

İ

FLOOR AREA 2M x 2M




**APPROXIMATE ASSEMBLY TIME** 

**2 PEOPLE ASSEMBLY** 

**REQUIRED ASSEMBLY SPACE** 

REQUIRED ASSEMBLY TOOLS




POZI SCREWDRIVER (NOT PROVIDED)



MEASURING TAGE (NOT PROVIDED)

ASSEMBLED DIMENSIONS




Max. Loading: 20kg (Top: 10kg, Shelf: 5kg each)

Item Code: 418408

# **Assembly Instructions**

## **PART LIST**

NO	PART LIST	QTY	NO	PART LIST	QTY
1	TOP PANEL	1	5	BACK SUPPORT LEG	2
2	BOTTOM PANEL	1	6	LEFT DOOR	1
3	SIDE PANEL	3	7	RIGHT DOOR	1
4	FRONT SUPPORT LEG	2			



## **HARDWARE LIST**

<b>A</b> x6	В	x6	С	x12	D	x6	Е	x16
					(			
Ø6x45mm	Q	Ø15x12mm	Ø8x30mm		Ø5x45mm			M6x12mm
QUICK FIT	(	CAM LOCK	DOWEL			SCREW		SCREW
<b>F</b> x8	G	x4	Н	x1	J	x2		
	•							
Ø4x10mm	11	3x16x10mm		4mm		Ø25x10mm		
SCREW		HANDLE		ALLEN KEY	A	DJUSTABLE FEET		

# Item Code: 418408 Assembly Instructions



## **Safety Advice and Care Advice**

KEEP ALL THE SAFETY ADVICE AND INSTRUCTIONS IN A SAFE PLACE FOR FUTURE REFERENCE!

### MARNING! RISK OF LOSS OF LIFE OR ACCIDENT

**TO INFANTS AND CHILDREN!** Never leave children unsupervised with the packaging materials. Danger of suffocation.

⚠ CAUTION! RISK OF INJURY! Make sure that all parts are undamaged and assembled correctly. Improper assembly carries a risk of injury. Damaged parts may affect the safety and function of the product.

- · Adult assembly required.
- Power tools are not recommended for this product.
- · Make sure that this product is stable & used only on a solid & flat surface.
- Do not use this product unless all screws and fixings are firmly secured.
- Do not leave children unsupervised! The product is not a climbing frame or a toy!
- Do not stand, sit or lean on this product
- Do not use this product as a step ladder or as a chopping surface.
- Do not lift or move the product when it is loaded.
- Do not load more than a total of 20kg (Top: 10kg, Shelf: 5kg each) onto the unit, otherwise there is a risk of injury and/or damage to the product
- Distribute weight evenly across the product so that it cannot overturn.
- Do not place hot items such as coffee cups directly on the surface(s) unless adequately thick table mats are used.
- Please periodically check all fittings and re-tighten as necessary.
- · For Indoor & Domestic use only.

#### Care instructions:


- · Wipe clean with a dry cloth.
- · Do not use scourers, abrasive or chemical solvents.
- Keep away from moisture and direct sunlight.
- · Keep away from fire and inflammable objects.


# KRISTEN COFFEE TABLE Item Code: 418408 **Assembly Instructions**

# SPECIAL TIPS FOR FITTING CAM-LOCKS **AND QUICKFIT**




WHEN FITTING CAMLOCK ENSURE STARTING POSITION IS CORRECT BEFORE YOU INSERT CONNECTING QUICKFIT TURN CLOCKWISE UNTIL SECURE





Quickfit head needs to be in centre




Item Code: 418408

**Assembly Instructions** 

STEP 1






x3


STEP 2





Item Code: 418408


**Assembly Instructions** 













Item Code: 418408

**Assembly Instructions** 





Item Code: 418408

**Assembly Instructions** 

