



T R O M S Ø

MODULAR TV UNIT

Item Code: 418587

Assembly Instructions


1.0hr

APPROXIMATE ASSEMBLY TIME

2 PERSON ASSEMBLY




FLOOR AREA
2Mx2M




REQUIRED ASSEMBLY SPACE

REQUIRED ASSEMBLY TOOLS



SOFT RUBBER HAMMER(Not Provided)




POZI SCREWDRIVER(Not Provided)



MEASURING TAPE(Not Provided)

ASSEMBLED DIMENSIONS



MAX. LOADING: 40KG (TOP: 10KG, SHELF: 5KG EACH)

1 - 14


TROMSO MODULAR TV UNIT

Item Code: 418587

Assembly Instructions

NO.	PART LIST	QTY	NO.	PART LIST	QTY
①	LEFT TOP PANEL	1	⑩	RIGHT SIDE PANEL	1
②	LEFT SIDE PANEL	1	⑪	BOTTOM PANEL	1
③	RIGHT SIDE PANEL	1	⑫	MIDDLE PANEL	1
④	BOTTOM PANEL	1	⑬	SUPPORT BAR	2
⑤	MIDDLE PANEL	1	⑭	SUPPORT BAR	1
⑥	SUPPORT BAR	2	⑮	SUPPORT BAR	1
⑦	BACK PANEL	1	⑯	LEFT DOOR	1
⑧	RIGHT TOP PANEL	1	⑰	RIGHT DOOR	1
⑨	LEFT SIDE PANEL	1	⑱	BACK PANEL	1








PART LIST



TROMSO MODULAR TV UNIT

Item Code: 418587 Assembly Instructions

HARDWARE LIST

A	x12	B	x12	C	x32	D	x16	E	x24
									
Dia.6x35mm		Dia.15x10mm		Dia.6x30mm		Dia.4x12mm		Dia.4x35mm	
QUICK FIT		CAMLOCK		WOOD DOWEL		SCREW		SCREW	
F	x32	G	x10	H	x32	I	x8	J	x4
									
Dia. 2x15mm				Dia.4x14mm					
BACK PANEL NAIL		STICKER		SCREW		LEG		HINGE	
K	x2	L	x4	M	x2	N	x2	O	x2
									
		Dia.4x22mm		Dia.6x50mm				Dia.6x16mm	
HANDLE		SCREW		WOOD DOWEL		NUT		SCREW	

TROMSO MODULAR TV UNIT

Item Code: 418587

Assembly Instructions



Safety Advice and Care Advice

KEEP ALL THE SAFETY ADVICE AND INSTRUCTIONS IN A SAFE PLACE FOR FUTURE REFERENCE!



WARNING! RISK OF LOSS OF LIFE OR ACCIDENT

TO INFANTS AND CHILDREN! Never leave children unsupervised with the packaging materials. Danger of suffocation.



CAUTION! RISK OF INJURY! Make sure that all parts are undamaged and assembled correctly. Improper assembly carries a risk of injury. Damaged parts may affect the safety and function of the product.

- Adult assembly required.
- Power tools are not recommended for the assembly of this product.
- Make sure that this product is stable & used only on a solid & flat surface.
- Do not use this product unless all screws and fixings are firmly secured.
- Do not leave children unsupervised! The product is not a climbing frame or a toy!
- Do not stand, sit or lean on this product.
- Do not use this product as a step ladder or as a chopping surface.
- Do not lift or move the product when it is loaded.
- Do not load more than a total of 40kg (Top: 10kg, shelf: 5kg each) onto the unit, otherwise there is a risk of injury and/or damage to the product.
- Distribute weight evenly across the product so that it cannot overturn.
- Do not place hot items such as coffee cups directly on the surface(s) unless adequately thick table mats are used.
- Please periodically check all fittings and re-tighten as necessary.
- For Indoor & Domestic use only.

Care instructions:

- Wipe clean with a dry cloth.
- Do not use scourers, abrasive or chemical solvents.
- Keep away from moisture and direct sunlight.
- Keep away from fire and inflammable objects.
- Store in a dry place.


TROMSO MODULAR TV UNIT

Item Code: 418587



Assembly Instructions

SPECIAL TIPS FOR FITTING CAM-LOCKS AND QUICKFIT

CAM-LOCK




WHEN FITTING CAMLOCK
ENSURE STARTING POSITION IS CORRECT
BEFORE YOU INSERT CONNECTING QUICKFIT
TURN CLOCKWISE UNTIL SECURE



Quickfit head needs to be in centre

QUICKFIT

Tighten until shoulder is flush with panel. Do not overtighten or leave too loose. (see example below)




TROMSO MODULAR TV UNIT

Item Code: 418587


Assembly Instructions

STEP 1




A		8
---	---	---

STEP 2




E		2
M		2




TROMSO MODULAR TV UNIT

Item Code: 418587 Assembly Instructions


STEP 3



B		2
---	---	---



STEP 4




C		4
E		4

TROMSO MODULAR TV UNIT

Item Code: 418587


Assembly Instructions

STEP 5




C		6
E		6

STEP 6



B		6
C		6




TROMSO MODULAR TV UNIT

Item Code: 418587


Assembly Instructions

STEP 7



H		16
I		4

STEP 8




F		16
---	--	----

TROMSO MODULAR TV UNIT

Item Code: 418587 Assembly Instructions


STEP 9

D		8
J		4
K		2
L		4



STEP 10

D		8
---	---	---




IMPORTANT: IF DOOR NOT ALIGNED

Screw A: You can adjust the doors up and down by releasing screw A.

Screw B: Release Screw B you can move the door forward or back till it is in the right position, then fully screw them.

Screw C: You can adjust the gap between the door and the side board by turning Screw C clockwise or anti-clockwise.




TROMSO MODULAR TV UNIT

Item Code: 418587

Assembly Instructions


STEP 11

A		4
---	---	---



STEP 12

C		4
E		4




TROMSO MODULAR TV UNIT

Item Code: 418587


Assembly Instructions

STEP 13



C		4
E		4

STEP 14




B		4
C		8
E		4

TROMSO MODULAR TV UNIT

Item Code: 418587


Assembly Instructions

STEP 15



H		16
I		4

STEP 16




F		16
---	--	----

TROMSO MODULAR TV UNIT


Item Code: 418587
Assembly Instructions

STEP 17

G		10
N		2
O		2



or



Domestic Use Only

B&M Retail, L24 8RJ, UK
www.bmstores.co.uk
B&M France SAS, 8 Rue du Bois Joli, 63800, France
MADE IN CHINA

