



### **UNDERSINK UNIT**

ITEM CODE: 418714
Assembly Instructions

1.0hr

2 PERSON ASSEMBLY

İ

FLOOR AREA 1.5Mx1.5M




**REQUIRED ASSEMBLY SPACE** 

REQUIRED ASSEMBLY TOOLS


APPROXIMATE ASSEMBLY TIME







ASSEMBLED DIMENSIONS




Max. Loading: 20kg (Top: 2kg, Shelf: 8kg each)

ITEM CODE: 418714
Assembly Instructions

NO	PART LIST	QTY	NO	PART LIST	QTY
1	TOP PANEL	1	7	BOTTOM PANEL	1
2	LEFT SIDE PANEL	1	8	BOTTOM BAR	1
3	RIGHT SIDE PANEL	1	9	BACK PANEL	2
4	RIGHT DOOR	1	10	BACK BAR	1
5	LEFT DOOR	1	11)	SUPPORT PANEL	1
6	MIDDLE PANEL	1			

#### **PARTS LIST**



ITEM CODE: 418714
Assembly Instructions

#### **HARDWARE LIST**

Α	x26	В	x26	С	x16	D	x16	Е	x4
QUICKFIT				0		(4))))))			
		С	CAMLOCK		8x30mm DOWEL	M3.5x12mm SCREW		HINGE	

F	x4	G	x12	Ι	x4	ı	x1		
				(					
M6x20mm SCREW			NALI		10x1.5mm	A	M4 ALLEN KEY		

ITEM CODE: 418714
Assembly Instructions



#### **Safety Advice and Care Advice**

KEEP ALL THE SAFETY ADVICE AND INSTRUCTIONS IN A SAFE PLACE FOR FUTURE REFERENCE!

#### **⚠ WARNING!** RISK OF LOSS OF LIFE OR ACCIDENT

**TO INFANTS AND CHILDREN!** Never leave children unsupervised with the packaging materials. Danger of suffocation.

⚠ CAUTION! RISK OF INJURY! Make sure that all parts are undamaged and assembled correctly. Improper assembly carries a risk of injury. Damaged parts may affect the safety and function of the product.


- · Adult assembly required.
- · Power tools are not recommended for the assembly of this product.
- Make sure that this product is stable & used only on a solid & flat surface.
- Do not use this product unless all screws and fixings are firmly secured.
- Do not leave children unsupervised! The product is not a climbing frame or a toy!
- · Do not stand, sit or lean on this product.
- Do not use this product as a step ladder or as a chopping surface.
- Do not lift or move the product when it is loaded.
- Do not load more than a total of 20kg (Top: 2kg, Shelf: 8kg each) onto the unit, otherwise there is a risk of injury and/or damage to the product.
- Distribute weight evenly across the product so that it cannot overturn.
- Do not place hot items such as coffee cups directly on the surface(s) unless adequately thick table mats are used.
- Please periodically check all fittings and re-tighten as necessary.
- For Indoor & Domestic use only.

#### Care instructions:

- Wipe clean with a dry cloth.
- · Do not use scourers, abrasive or chemical solvents.
- · Keep away from moisture and direct sunlight.
- · Keep away from fire and inflammable objects.
- Store in a dry place.

ITEM CODE: 418714
Assembly Instructions


# SPECIAL TIPS FOR FITTING CAM-LOCKS



CORRECT


**WRONG** 


Quickfit head needs to be in centre





ITEM CODE: 418714
Assembly Instructions
















STEP 2





ITEM CODE: 418714
Assembly Instructions








B x 3








B x 16



ITEM CODE: 418714
Assembly Instructions










B x 7





ITEM CODE: 418714
Assembly Instructions





#### IMPORTANT: IF DOOR NOT ALIGNED


Screw A: You can adjust the doors up and down by releasing screw A.


Screw B: Release screw B you can move the door forward or back till it is in the right position, then fully screw them.


Screw C: You can adjust the gap between the door and the side board by turning screw C clockwise or anti-clockwise.

ITEM CODE: 418714
Assembly Instructions










ITEM CODE: 418714
Assembly Instructions







B&M Retail, L24 8RJ, UK www.bmstores.co.uk B&M France SAS, 8 Rue du Bois Joli, 63800, France MADE IN CHINA