


HOLLYWOOD CORNER VANITY UNIT

Item Code: 425739

Assembly Instructions

1.5hr

APPROXIMATE ASSEMBLY TIME 2 PEOPLE ASSEMBLY



FLOOR AREA
2M x 2M




REQUIRED ASSEMBLY SPACE


REQUIRED ASSEMBLY TOOLS




DRILL DRIVER (Not Provided)



POZI SCREWDRIVER (Not Provided)




HAMMER (Not Provided)



MEASURING TAPE (Not Included)

ASSEMBLED DIMENSIONS



MAX. LOADING: 22KG (TOP: 10KG / DRAWER: 2KG EACH / SHELF: 2KG EACH)


HOLLYWOOD CORNER VANITY UNIT

Item Code: 425739

Assembly Instructions

NO	PART LIST	QTY	NO	PART LIST	QTY
1	Table top	1	11	Mirror panel	1
2	Side panel	2	12	Shelf panel	2
3	Support panel	1	13	Mirror panel	1
4	Bottom panel	1	14	Drawer front panel	1
5	Left side panel	1	15	Drawer left side panel	1
6	Right side panel	1	16	Drawer right side panel	1
7	Shelf panel	1	17	Drawer back panel	1
8	Back panel	1	18	Drawer bottom panel	1
9	Back panel	1	19	Back panel	1
10	Mirror panel	1			

PARTS LIST











HOLLYWOOD CORNER VANITY UNIT

Item Code: 425739

Assembly Instructions

HARDWARE LIST

A	x36	B	x36	C	x24	D	x12	E	x14
									
M6x35mm		ø15x11mm		ø8x30mm		M7x50mm		M3.5x14mm	
QUICKFIT		CAMLOCK		WOODE DOWEL		SCREW		SCREW	
F	x2	G	x3	H	x3	I	x20	J	x40
									
CONNECT THE HING		M6x26mm		ø15x1mm		M4x5mm		M3x14mm	
		SCREW		WASHER		SCREW		SCREW	
K	x1	L	x12	M	x6	N	x19	O	x1
									
WIRE WETHPLUG+6 LAMP HOLDER		PLASTIC WASHER		LED BULB		IRON NAIL		WIRE FIXING CLIP	
P	x14	Q	x4	R	x2	S	x2	T	x2
									
M3x12mm		ø18mm		M6x12mm		73x16x25mm		M4x35mm	
SCREW		ADHESIVE STICKER		SCREW		METAL BRACKET		SCREW	
U	x2	V	x1	CL	x5	CR	x5	DL	x5
									
WALL PLUG		M4		250mm		250mm		250mm	
		ALLEN KEY		SLIDE RAIL		SLIDE RAIL		SLIDE RAIL	
DR	x5								
									
250mm									
SLIDE RAIL									

HOLLYWOOD CORNER VANITY UNIT

Item Code: 425739

Assembly Instructions



Safety Advice and Care Advice

KEEP ALL THE SAFETY ADVICE AND INSTRUCTIONS IN A SAFE PLACE FOR FUTURE REFERENCE!



WARNING! RISK OF LOSS OF LIFE OR ACCIDENT

TO INFANTS AND CHILDREN! Never leave children unsupervised with the packaging materials. Danger of suffocation.

CAUTION! RISK OF INJURY! Make sure that all parts are undamaged and assembled correctly. Improper assembly carries a risk of injury. Damaged parts may affect the safety and function of the product.

- Adult assembly required.
- Power tools are not recommended for the assembly of this product.
- Make sure that this product is stable & used only on a solid & flat surface.
- Do not use this product unless all screws and fixings are firmly secured.
- Do not leave children unsupervised! The product is not a climbing frame or a toy!
- Do not stand, sit or lean on this product.
- Do not use this product as a step ladder or as a chopping surface.
- Do not lift or move the product when it is loaded.
- Do not load more than a total of 22kg (Top: 10kg / Drawer: 2kg each / Shelf: 2kg each) onto the unit, otherwise there is a risk of injury and/or damage to the product.
- Distribute weight evenly across the product so that it cannot overturn.
- Do not place hot items such as coffee cups directly on the surface(s) unless adequately thick table mats are used.
- Please periodically check all fittings and re-tighten as necessary.
- For Indoor & Domestic use only.

Care instructions:

- Wipe clean with a dry cloth.
- Do not use scourers, abrasive or chemical solvents.
- Keep away from moisture and direct sunlight.
- Keep away from fire and inflammable objects.
- Store in a dry place.

HOLLYWOOD CORNER VANITY UNIT

Item Code: 425739



Assembly Instructions

SPECIAL TIPS FOR FITTING CAM-LOCKS AND QUICKFIT

CAM-LOCK




WHEN FITTING CAMLOCK
ENSURE STARTING POSITION IS CORRECT
BEFORE YOU INSERT CONNECTING QUICKFIT
TURN CLOCKWISE UNTIL SECURE



Quickfit head needs to be in centre

QUICKFIT

Tighten until shoulder is flush with panel. Do not overtighten or leave too loose. (see example below)



HOLLYWOOD CORNER VANITY UNIT

Item Code: 425739

Assembly Instructions

NOTE: Supplied wall plugs are only suitable for use in masonry walls.

If you have any doubts about using the correct plug for your wall, please seek professional advice. Failure of the product due to using incorrect fixings is the responsibility of the installer.



IMPORTANT:

When drilling into walls, always check for hidden wires or pipes, etc.




Tips & Tricks

**Make sure that the hardware used is suitable for supporting your unit.
Please consult a qualified tradesperson if unsure.**

- ☑ If you are unsure, please select a larger screw and wall plug.
- ☑ Ensure that you use the recommended drill bit to match the wall plug and hole size.
- ☑ Take extra care when drilling high walls, ceiling and ceramic tiles. Ensure wall plugs are inserted beyond the thickness of the ceramic tiles to avoid splitting or cracking.
- ☑ Ensure that wall plugs are well fitted and are a tight fit in the drilled hole.


Types Of Walls

Use one of the following types of wall plug (not included) if your walls are made of brick, breeze block, concrete, stone or wood. Screws may be able to be fixed directly to solid wood walls as they will provide a secure anchor point.




1. General Purpose Wall Plug

Generally, aerated blocks should not be used to support heavy loads, use a specialist fitting in this case. For light loads, general purpose wall plugs can be used.




2. Plasterboard Wall Plug

For use when attaching light loads onto plasterboard partitions.




3. Cavity Fixing Wall Plug

For use with plasterboard partitions or hollow wooden doors.




4. Cavity Fixing Heavy Duty Wall Plug

For use when fitting or supporting heavy loads such as shelving and wall cabinets.



5. Hammer Fixing Wall Plug

For use with concrete block or brick walls, or walls stuck with plasterboard. The hammer fixing allows it to be fixed to the wall rather than the plasterboard. Always check the fixing is secure to the retaining wall.



6. Shield Anchor Wall Plug Heavy Loads


For use with concrete or brick walls, or for use with heavier loads such as TV & HiFi speakers and satellite dishes, etc.

HOLLYWOOD CORNER VANITY UNIT



Item Code: 425739

Assembly Instructions

STEP 1



STEP 2




HOLLYWOOD CORNER VANITY UNIT


Item Code: 425739

Assembly Instructions

STEP 3



STEP 4





HOLLYWOOD CORNER VANITY UNIT


Item Code: 425739

Assembly Instructions


STEP 5




Dx4



Gx3





Hx3




Cx4

STEP 6



Ex12




Fx2

HOLLYWOOD CORNER VANITY UNIT


Item Code: 425739

Assembly Instructions

STEP 7



STEP 8





HOLLYWOOD CORNER VANITY UNIT




Item Code: 425739

Assembly Instructions

STEP 9



STEP 10






HOLLYWOOD CORNER VANITY UNIT





Item Code: 425739

Assembly Instructions

STEP 11



STEP 12





HOLLYWOOD CORNER VANITY UNIT


Item Code: 425739

Assembly Instructions

STEP 13



STEP 14




HOLLYWOOD CORNER VANITY UNIT


Item Code: 425739

Assembly Instructions

STEP 15



STEP 16




HOLLYWOOD CORNER VANITY UNIT

Item Code: 425739

Assembly Instructions


STEP 17



Lx6



Mx6





HOLLYWOOD CORNER VANITY UNIT



Item Code: 425739

Assembly Instructions

STEP 18



STEP 19




HOLLYWOOD CORNER VANITY UNIT


Item Code: 425739

Assembly Instructions





STEP 20



Ux2



Tx2



WARNING: Anti-tipping hardware is only a deterrent. It is not a substitute for proper adult supervision. Young children may be injured by tipping furniture and the use of a tipping restraint is highly recommended, could provide protection against the unexpected tipping of furniture due to improper use.

Please ensure the anti-tipping hardware provided is suitable for your wall or else it might damage your wall during installation.

Operating Instructions

Please read these instructions thoroughly before use and retain for future reference

Getting Started

- Remove all parts from the box.
- Retain instructions for future reference.
- Place the packaging inside the box to either store or dispose of safely.
- Input Rating: 220-240V~50Hz 18W (3W x 6)
- Bulb type: E27 3W
- This product contains a light source of energy efficiency class F.

In the Box

- Karina Bailey Hollywood Corner Vanity Unit
- Fixings
- Assembly Instruction+Operating Instructions

Important Safety Instructions

- For indoor use only
- Do not use this light set if the insulation cable is damaged. If the cable is damaged the light set must be discarded.
- Choose a suitable location for the dressing table and ensure that the socket that you use is close enough and that the cable will reach the socket without becoming an obstacle / trip hazard
- Always switch off and unplug when not in use
- Always switch off and unplug before carrying out maintenance and / or cleaning.
- Domestic use only.
- Do not dispose of this product in fire.
- Install the unit away from heat sources, direct sunlight, humidity and water.
- Do not operate the unit if it has been exposed to water, moisture or any other liquids to prevent electric shock, explosion and/or injury to yourself and damage to the unit. Wiring by registered electrical technician only.
- Do not use the unit if it has been dropped or damaged in any way.
- Repairs to electrical equipment should only be performed by a qualified electrician. Improper repairs may place the user at serious risk.
- Do not use the unit with wet hands.
- Do not put objects into any of the openings.
- Keep the unit free from dust, lint etc.
- Do not use this unit for anything other than its intended use.
- Keep the cable out of reach of children.
- Do not use abrasive cleaning solvents to clean.
- Do not connect the chain to supply while it is in the packing or on a reel.
- Do not connect this chain electrically to another chain.
- Do not insert bulb whilst the light set is plugged in.

SET UP:

- Install the desk for Indoor use only. Ensure all parts are fixed securely before use.
- Lift all the spare parts out of box.
- Review the Assembly Instruction to familiarize yourself with the desk's components, accessories, and set-up.
- Please complete steps 1-19 to assemble the desk.
- Plug into your chosen socket and switch on. To switch the light set on use the switch located on side of unit.

UK Declaration

This product is intended for use within the UK.

This appliance complies with the below listed UK directives.

Electromagnetic Compatibility Regulations 2016

Electrical Equipment (Safety) Regulations 2016

The Restriction of the Use of Certain Hazardous Substances in Electrical and Electronic Equipment Regulations 2012

The Ecodesign for Energy-Related Products and Energy Information (Amendment) (EU Exit) Regulations 2019

B&M Retail Ltd, Dakota Drive, Speke,
Liverpool, L24 8RJ, UK, www.bmstores.co.uk
B&M France SAS, 8 Rue du Bois Joli,
63800, Cournon-d'Auvergne, France
MADE IN CHINA

 Waste electrical products should not be disposed of with household waste. Please recycle at your local recycling facility. Check with your local authority for recycling advice.

