





EDEN
MID-CENTURY ARMCHAIR
 Item Code: 426207
 Assembly Instructions

 ① x1	 ② x1	 M8*50MM ① x8	 ① x1
	 ③ x1	 ① x4	 ① x8




Max. Loading: 100kg




Warning:

Do not leave children unsupervised!
 The product is not a climbing frame or a toy!
 Make sure that this product is standing on a solid, level surface.
 Make sure that no body, especially a child, climbs on or leans against the product.
 Check that the product is stable before using it.
 Make sure that all fixings are secure before use.
 Do not use this chair as a step ladder.
 Use the product only for seating, one person at a time.
 Care and Cleaning: Wipe clean with a damp cloth.

- 1** Loosely tighten screws until all screws are inserted.
 If the screw cap cannot push in, tap in gently with a hammer.



- 2** Loosely tighten screws until all screws are inserted.
 If the screw cap cannot push in, tap in gently with a hammer.



Domestic use only

B&M Retail, L24 8RJ, UK
www.bmstores.co.uk
 B&M France SAS, 8 Rue du Bois Joli, 63800, France
 MADE IN CHINA

