



DOUBLE WARDROBE WITH 2 DRAWERS

Item code: 397650

Assembly Instructions


60 min

APPROXIMATE ASSEMBLY TIME

2 PEOPLE ASSEMBLY




FLOOR AREA
1.5M x1.5M



REQUIRED ASSEMBLY SPACE

ASSEMBLED DIMENSIONS



MAX. LOADING: 25KG (CABINET: 5KG / HANGING RAIL: 10KG / DRAWER: 5KG EACH)

IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY

Packaging is not a toy. Keep away from babies and children. Keep away from fire and inflammable objects. Periodically ensure all the screws and fixings are secure and the item is stable.

After use the product for a period of time, please check on the product every time before use. Do not leave children unsupervised. The product is not a climbing frame or a toy.

















Make sure that this product is standing on a solid level surface. Check that the product is stable before using it. Please take care when moving the table, it should always be lifted to be moved.

Please take care when placing any heavy items on the table. Make sure that all fixings are secure before use. Care and cleaning: Wipe clean with dry cloth. Do not use abrasives, solvents and bleach products.

SIMPLY DOUBLE WARDROBE WITH 2 DRAWERS

Item code: 397650
Assembly Instructions
















PART LIST

 ① x1	 ② x1	 ③ x1	 ④ x1
 ⑤ x1	 ⑥ x1	 ⑦ x2	 ⑧ x2
 ⑨ x2	 ⑩ x3	 ⑪ x2	 ⑫ x2
 ⑬ x2	 ⑭ x2	 ⑮ x2	 ⑯ x2
 ⑰ x1			

SIMPLY DOUBLE WARDROBE WITH 2 DRAWERS

Item code: 397650
Assembly Instructions

HARDWARE LIST

 M6x35mm A x14	 M15x10mm B x22	 M3.5x12mm C x12	 D x6
 M3x12mm E x26	 F x20	 G x4	 M3x14mm H x2
 M2x16mm I x34	 M4x35mm J x12	 M5x20mm K x12	 L x6
 M x2	 M4x12mm N x2	 M6x30mm O x2	 P x1
 M3.5x14mm Q x16	 R x2	 M5x40mm S x20	 T x4
 M6x50mm U x4	 V x1	 W x4	 X x1
 Y x2	 Z x4		

SIMPLY DOUBLE WARDROBE WITH 2 DRAWERS

Item code: 397650
Assembly Instructions



Safety Advice and Care Advice

KEEP ALL THE SAFETY ADVICE AND INSTRUCTIONS IN A SAFE PLACE FOR FUTURE REFERENCE!

⚠ WARNING! RISK OF LOSS OF LIFE OR ACCIDENT TO INFANTS AND CHILDREN! Never leave children unsupervised with the packaging materials. Danger of suffocation.

⚠ CAUTION! RISK OF INJURY! Make sure that all parts are undamaged and assembled correctly. Improper assembly carries a risk of injury. Damaged parts may affect the safety and function of the product.

- Adult assembly required.
- Power tools are not recommended for this product.
- Make sure that this product is stable & used only on a solid & flat surface.
- Do not use this product unless all screws and fixings are firmly secured.
- Do not leave children unsupervised! The product is not a climbing frame or a toy!
- Do not stand, sit or lean on this product.
- Do not use this product as a step ladder or as a chopping surface.
- Do not lift or move the product when it is loaded.
- Do not load more than a total of 10kg on the hanging rail, 5kg on the drawer, 5kg on cabinet onto the unit, otherwise there is a risk of injury and/or damage to the product.
- Distribute weight evenly across the product so that it cannot overturn.
- Do not place hot items such as coffee cups directly on the surface(s) unless adequately thick table mats are used.
- Please periodically check all fittings and re-tighten as necessary.
- For Indoor & Domestic use only.

Care instructions:

- Wipe clean with a dry cloth.
- Do not use scourers, abrasive or chemical solvents.
- Keep away from moisture and direct sunlight.
- Keep away from fire and inflammable objects.
- Store in a dry place.




PLEASE DO NOT IRON OR WASH THE BASKETS



SIMPLY DOUBLE WARDROBE WITH 2 DRAWERS

Item code: 397650
Assembly Instructions

SPECIAL TIPS FOR FITTING CAM-LOCKS AND QUICKFIT




CAM-LOCK



Quickfit head needs to be in centre

QUICKFIT

Tighten until shoulder is flush with panel. Do not overtighten or undertighten (see example below)



SIMPLY DOUBLE WARDROBE WITH 2 DRAWERS

Item code: 397650 Assembly Instructions

NOTE: Supplied wall plugs are only suitable for use in masonry walls.

If you have any doubts about using the correct plug for your wall, please seek professional advice. Failure of the product due to using incorrect fixings is the responsibility of the installer.



IMPORTANT:

When drilling into walls, always check for hidden wires or pipes, etc.



Tips & Tricks


Make sure that the hardware used is suitable for supporting your unit.

Please consult a qualified tradesperson if unsure.

- ✓ If you are unsure, please select a larger screw and wall plug.
- ✓ Ensure that you use the recommended drill bit to match the wall plug and hole size.
- ✓ Take extra care when drilling high walls, ceiling and ceramic tiles. Ensure wall plugs are inserted beyond the thickness of the ceramic tiles to avoid splitting or cracking.
- ✓ Ensure that wall plugs are well fitted and are a tight fit in the drilled hole.


Types Of Walls

Use one of the following types of wall plug (not included) if your walls are made of brick, breeze block, concrete, stone or wood. Screws may be able to be fixed directly to solid wood walls as they will provide a secure anchor point.




1. General Purpose Wall Plug

Generally, aerated blocks should not be used to support heavy loads, use a specialist fitting in this case. For light loads, general purpose wall plugs can be used.




2. Plasterboard Wall Plug

For use when attaching light loads onto plasterboard partitions.




3. Cavity Fixing Wall Plug

For use with plasterboard partitions or hollow wooden doors.




4. Cavity Fixing Heavy Duty Wall Plug

For use when fitting or supporting heavy loads such as shelving and wall cabinets.



5. Hammer Fixing Wall Plug

For use with concrete block or brick walls, or walls stuck with plasterboard. The hammer fixing allows it to be fixed to the wall rather than the plasterboard. Always check the fixing is secure to the retaining wall.




6. Shield Anchor Wall Plug Heavy Loads

For use with concrete or brick walls, or for use with heavier loads such as TV & HiFi speakers and satellite dishes, etc.


SIMPLY DOUBLE WARDROBE WITH 2 DRAWERS

Item code: 397650
Assembly Instructions


STEP 1



STEP 2



B x 8



T x 4




U x 4

SIMPLY DOUBLE WARDROBE WITH 2 DRAWERS

Item code: 397650
Assembly Instructions

STEP 3



M3x12mm
E x 6




R x 1



M3.5x14mm
Q x 2

STEP 4



M3x12mm
E x 6



R x 1




M3.5x14mm
Q x 2


SIMPLY DOUBLE WARDROBE WITH 2 DRAWERS

Item code: 397650
Assembly Instructions

STEP 5





STEP 6



SIMPLY DOUBLE WARDROBE WITH 2 DRAWERS

Item code: 397650
Assembly Instructions


STEP 7



M6x35mm
A x 4




M3x14mm
H x 2



X x 1

STEP 8




M3.5x12mm
C x 12




D x 2




M3x12mm
E x 2



M5x20mm
K x 4



L x 6




Y x 2


SIMPLY DOUBLE WARDROBE WITH 2 DRAWERS

Item code: 397650
Assembly Instructions


STEP 9



B x 4



STEP 10



G x 4




**M2x16mm
I x 34**



P x 1




Z x 4




SIMPLY DOUBLE WARDROBE WITH 2 DRAWERS

Item code: 397650
Assembly Instructions


STEP 11




M3.5x14mm
Q x 12



STEP 12



M4x35mm
J x 10



x2

Item code: 397650
Assembly Instructions

Assembly Instructions

STEP 13

Assembly Details:

- Drawer Front (16):** Attach to side panel (11) using screws **A x5** and **D x2**.
- Drawer Front (16):** Attach to bottom panel (14) using screws **B x5** and **K x8**.

Parts List:

- A x5:** M6x35mm screw
- B x5:** M5x20mm screw
- D x2:** D x 4
- K x8:** K x 8

Assembly Instructions:

- Insert the drawer front (16) into the cabinet.
- Attach the drawer front (16) to the side panel (11) using screws A (x5) and D (x2).
- Attach the drawer front (16) to the bottom panel (14) using screws B (x5) and K (x8).

Final Assembly: The final assembly shows the cabinet with drawers 11, 12, 13, 14, and 16. The drawers are labeled 11, 12, 13, 14, and 16.

x2

P 14

M3x12mm
E x 12

E x 6

W² x2

x2



x2

SIMPLY DOUBLE WARDROBE WITH 2 DRAWERS

Item code: 397650
Assembly Instructions

STEP 16

WALL



M4x35mm
J x 2




M x 2



M4x12mm
N x 2



M6x30mm
O x 2



WARNING: Anti-tipping hardware is only a deterrent. It is not a substitute for proper adult supervision. Young children may be injured by tipping furniture and the use of a tipping restraint is highly recommended. This hardware, when properly installed, could provide protection against the unexpected tipping of furniture due to improper use.

Please ensure the anti-tipping hardware provided is suitable for your wall or else it might damage your wall during installation.



MAX. LOADING: 25KG
(CABINET: 5KG / HANGING RAIL: 10KG / DRAWER: 5KG EACH)



Domestic use only
B&M Retail, L24 8RJ, UK
Homesavers, 5 Old Dublin Rd, Dublin, A94 K1H5
MADE IN CHINA