



Signature
Collection

LAUREL 3 DOOR WARDROBE

Item Code:435625

Assembly Instructions

1.5 hrs

APPROXIMATE ASSEMBLY TIME



2 PERSON ASSEMBLY

FLOOR AREA
1.5M x 1.5M



REQUIRED ASSEMBLY SPACE

REQUIRED ASSEMBLY TOOLS



POZI SCREWDRIVER (Not Provided)




HAMMER (Not Provided)



MEASURING TAPE (Not Included)

ASSEMBLED DIMENSION



MAX. LOADING: 42KG (SHELF: 5KG EACH / HANGING RAIL: 7KG / CABINET: 10KG)

1-15

SIGNATURE COLLECTION LAUREL 3 DOOR WARDROBE


Item Code:435625
Assembly Instructions

NO.	PART LIST	QTY	NO.	PART LIST	QTY
①	TOP PANEL	1	⑨	MIRROR DOOR PANEL	1
②	BOTTOM PANEL	1	⑩	FRONT KICK BOARD	1
③	LEFT SIDE PANEL	1	⑪	LEFT BACK PANEL	3
④	MIDDLE PANEL	1	⑫	BACK SIDE SUPPORT BAR	2
⑤	RIGHT SIDE PANEL	1	⑬	BACK KICK BOARD	1
⑥	LEFT SHELF PANEL	1	⑭	RIGHT BACK PANEL	1
⑦	RIGHT SHELF PANEL	3	⑮	HANGING RAIL	1
⑧	DOOR PANEL	2			

SIGNATURE COLLECTION LAUREL 3 DOOR WARDROBE

Item Code:435625
Assembly Instructions












PART LIST



SIGNATURE COLLECTION LAUREL 3 DOOR WARDROBE

Item Code:435625
Assembly Instructions

HARDWARE LIST

A	x50	B	x50	C	x32	D	x2	E	x12
									
Dia.6x35mm		Dia.15x11mm		Dia.8x30mm		Dia.8x50mm		Dia.7x50mm	
QUICKFIT		CAM LOCK		WOODEN DOWEL		WOODEN DOWEL		SCREW	
F	x64	G	x9	H	x3	I	x2	J	x77
									
Dia.3.5x14mm									
SCREW		HINGE		HANDLE		BAFFLE		SCREW	
K	x6	L	x2	M	x2	N	x2	O	x9
									
Dia.6*12mm				Dia.4x35mm					
SCREW		ANTI-TIP WALL FIXINGS		SCREW		WALL PLUG		BACKBOARD FASTENER	
P	x1								
									
M4									
ALLEN KEY									

SIGNATURE COLLECTION LAUREL 3 DOOR WARDROBE

Item Code:435625

Assembly Instructions



Safety Advice and Care Advice

KEEP ALL THE SAFETY ADVICE AND INSTRUCTIONS IN A SAFE PLACE FOR FUTURE REFERENCE!



WARNING! RISK OF LOSS OF LIFE OR ACCIDENT

TO INFANTS AND CHILDREN! Never leave children unsupervised with the packaging materials. Danger of suffocation.



CAUTION! RISK OF INJURY! Make sure that all parts are undamaged and assembled correctly. Improper assembly carries a risk of injury. Damaged parts may affect the safety and function of the product.

- Adult assembly required.
- Power tools are not recommended for the assembly of this product.
- Make sure that this product is stable & used only on a solid & flat surface.
- Do not use this product unless all screws and fixings are firmly secured.
- Do not leave children unsupervised! The product is not a climbing frame or a toy!
- Do not stand, sit or lean on this product
- Do not use this product as a step ladder or as a chopping surface.
- Do not lift or move the product when it is loaded.
- Do not load more than a total of 42kg (Shelf: 5kg Each / Hanging Rail: 7kg / Caninet: 10kg) onto the unit, otherwise there is a risk of injury and/or damage to the product
- Distribute weight evenly across the product so that it cannot overturn.
- Do not place hot items such as coffee cups directly on the surface(s) unless adequately thick table mats are used.
- Please periodically check all fittings and re-tighten as necessary.
- For Indoor & Domestic use only.

Care instructions:

- Wipe clean with a dry cloth.
- Do not use scourers, abrasive or chemical solvents.
- Keep away from moisture and direct sunlight.
- Keep away from fire and inflammable objects.
- Store in a dry place.


SIGNATURE COLLECTION LAUREL 3 DOOR WARDROBE

Item Code:435625



Assembly Instructions

SPECIAL TIPS FOR FITTING CAM-LOCKS AND QUICKFIT

CAM-LOCK




WHEN FITTING CAMLOCK
ENSURE STARTING POSITION IS CORRECT
BEFORE YOU INSERT CONNECTING QUICKFIT
TURN CLOCKWISE UNTIL SECURE



Quickfit head needs to be in centre

QUICKFIT

Tighten until shoulder is flush with panel. Do not overtighten or leave too loose. (see example below)



SIGNATURE COLLECTION LAUREL 3 DOOR WARDROBE

Item Code:435625 Assembly Instructions

NOTE: Supplied wall plugs are only suitable for use in masonry walls.

If you have any doubts about using the correct plug for your wall, please seek professional advice. Failure of the product due to using incorrect fixings is the responsibility of the installer.



IMPORTANT:

When drilling into walls, always check for hidden wires or pipes, etc.




Tips & Tricks

Make sure that the hardware used is suitable for supporting your unit.
Please consult a qualified tradesperson if unsure.

- ☑ If you are unsure, please select a larger screw and wall plug.
- ☑ Ensure that you use the recommended drill bit to match the wall plug and hole size.
- ☑ Take extra care when drilling high walls, ceiling and ceramic tiles. Ensure wall plugs are inserted beyond the thickness of the ceramic tiles to avoid splitting or cracking.
- ☑ Ensure that wall plugs are well fitted and are a tight fit in the drilled hole.


Types Of Walls

Use one of the following types of wall plug (not included) if your walls are made of brick, breeze block, concrete, stone or wood. Screws may be able to be fixed directly to solid wood walls as they will provide a secure anchor point.




1. General Purpose Wall Plug

Generally, aerated blocks should not be used to support heavy loads, use a specialist fitting in this case. For light loads, general purpose wall plugs can be used.




2. Plasterboard Wall Plug

For use when attaching light loads onto plasterboard partitions.




3. Cavity Fixing Wall Plug

For use with plasterboard partitions or hollow wooden doors.




4. Cavity Fixing Heavy Duty Wall Plug

For use when fitting or supporting heavy loads such as shelving and wall cabinets.



5. Hammer Fixing Wall Plug

For use with concrete block or brick walls, or walls stuck with plasterboard. The hammer fixing allows it to be fixed to the wall rather than the plasterboard. Always check the fixing is secure to the retaining wall.





6. Shield Anchor Wall Plug Heavy Loads

For use with concrete or brick walls, or for use with heavier loads such as TV & HiFi speakers and satellite dishes, etc.

SIGNATURE COLLECTION LAUREL 3 DOOR WARDROBE


Item Code:435625
Assembly Instructions

STEP 1



Dia.6x35mm
AX8

STEP 2



Dia.15x11mm
BX8





Dia.8x30mm
CX4

SIGNATURE COLLECTION LAUREL 3 DOOR WARDROBE


Item Code:435625
Assembly Instructions

STEP 3



Dia.6x35mm
AX16

STEP 4



Dia.15x11mm
BX9



Dia.8x30mm
CX4




Dia.8x50mm
DX2

SIGNATURE COLLECTION LAUREL 3 DOOR WARDROBE

Item Code:435625
Assembly Instructions

STEP 5





Dia.8x30mm
CX2


Dia.7x50mm
EX3


M4
PX1

STEP 6





Dia.6x35mm
AX26

SIGNATURE COLLECTION LAUREL 3 DOOR WARDROBE

Item Code:435625
Assembly Instructions

STEP 7




Dia.15x11mm
BX14



Dia.8x30mm
CX10

STEP 8



Dia.15x11mm
BX7



Dia.6x12mm
KX2




M4
PX1


SIGNATURE COLLECTION LAUREL 3 DOOR WARDROBE

Item Code:435625
Assembly Instructions

STEP 9



Dia.15x11mm
BX12



Dia.8x30mm
CX6




Dia.6x12mm
KX2




M4
PX1


STEP 10




Dia.3.5x14mm
FX2



IX1



Dia.6x12mm
KX2



LX2




M4
PX1

12-15

SIGNATURE COLLECTION LAUREL 3 DOOR WARDROBE

Item Code:435625
Assembly Instructions

STEP 11





Dia.8x30mm
CX6


Dia.7x50mm
EX9


M4
PX1

STEP 12





JX77


OX9


SIGNATURE COLLECTION LAUREL 3 DOOR WARDROBE

Item Code:435625
Assembly Instructions


STEP 13



Dia.3.5x14mm
FX24





GX9




HX3


STEP 14



Dia.3.5x14mm
FX38



IX1



IMPORTANT: IF DOOR NOT ALIGNED

Screw A: You can adjust the doors up and down by releasing screw A.


Screw B: Release Screw B you can move the door forward or back till it is in the right position, then fully screw them.

Screw C: You can adjust the gap between the door and the side board by turning Screw C clockwise or anti-clockwise.

SIGNATURE COLLECTION LAUREL 3 DOOR WARDROBE


Item Code:435625
Assembly Instructions

STEP 17



Dia. 4x35mm

MX2



NX2



WARNING:

Anti-tipping hardware is only a deterrent.
It is not a substitute for proper adult supervision.

Young children may be injured by tipping furniture and the use of a tipping restraint is highly recommended.

This hardware, when properly installed, could provide protection against the unexpected tipping of furniture due to improper use.

Please ensure the anti-tipping hardware provided is suitable for your wall or else it might damage your wall during installation.

Domestic Use Only



B&M Retail, L24 8RJ, UK
www.bmstores.co.uk

B&M France SAS, 8 Rue du Bois Joli, 63800, France

MADE IN CHINA