



Signature
Collection

SEVILLE 2 DOOR TV UNIT

ITEM CODE: 435629

Assembly Instructions

1 hr

APPROXIMATE ASSEMBLY TIME




2 PERSONS ASSEMBLY

FLOOR AREA
2M X 2M




REQUIRED ASSEMBLY SPACE

REQUIRED ASSEMBLY TOOLS



POZI SCREWDRIVER (Not Included)

ASSEMBLED DIMENSIONS




MAX. LOADING: 40KG (TOP: 20KG, SHELF: 5KG EACH)

SIGNATURE COLLECTION SEVILLE 2 DOOR TV UNIT

ITEM CODE: 435629
Assembly Instructions

NO	PART LIST	QTY	NO	PART LIST	QTY
①	TOP PANEL	1	⑧	MIDDLE SHELF	4
②	BOTTOM PANEL	1	⑨	WRAPPING PANEL	2
③	LEFT SIDE MIDDLE PANEL	1	⑩	BACK PANEL	1
④	RIGHT SIDE MIDDLE PANEL	1	⑪	LEFT SIDE FRONT DOOR	1
⑤	LEFT SIDE MIDDLE PANEL	1	⑫	RIGHT SIDE FRONT DOOR	1
⑥	RIGHT SIDE MIDDLE PANEL	1	⑬	LEG	4
⑦	MIDDLE SHELF	1	⑭	ADJUSTABLE LEG	2

PART LIST






SIGNATURE COLLECTION SEVILLE 2 DOOR TV UNIT

ITEM CODE: 435629

Assembly Instructions

HARDWARE LIST

A	x8	B	x8	C	x24	D	x8	E	x4	F	x24	G	x6
													
QUICK FIT		CAM LOCK		WOOD DOWEL		SCREW M4 x 35mm		METAL HINGE		SCREW M4 x 12mm		METAL CONNECTOR	
H	x4	I	x1	J	x8	K	x24	L	x2	M	x4	N	x4
													
SHELF SUPPORT		WRENCH		BOLT M7 x 40mm		SCREW M4 x 12mm		DOOR PUSH LATCH		SCREW M3 x 12mm		FLOOR PROTECTOR	
O	x8	P	x8	Q	x8								
													
SCREW M4 x 25mm		BACK PANEL SUPPORTER		SCREW M3 x 16mm									

SIGNATURE COLLECTION SEVILLE 2 DOOR TV UNIT

ITEM CODE: 435629

Assembly Instructions



Safety Advice and Care Advice

KEEP ALL THE SAFETY ADVICE AND INSTRUCTIONS IN A SAFE PLACE FOR FUTURE REFERENCE!



WARNING! RISK OF LOSS OF LIFE OR ACCIDENT

TO INFANTS AND CHILDREN! Never leave children unsupervised with the packaging materials. Danger of suffocation.



CAUTION! RISK OF INJURY! Make sure that all parts are undamaged and assembled correctly. Improper assembly carries a risk of injury. Damaged parts may affect the safety and function of the product.

- Adult assembly required.
- Power tools are not recommended for the assembly of this product.
- Make sure that this product is stable & used only on a solid & flat surface.
- Do not use this product unless all screws and fixings are firmly secured.
- Do not leave children unsupervised! The product is not a climbing frame or a toy!
- Do not stand, sit or lean on this product.
- Do not use this product as a step ladder or as a chopping surface.
- Do not lift or move the product when it is loaded.
- Do not load more than a total of 40kg (Top: 20kg, Shelf: 5kg each) onto the unit, otherwise there is a risk of injury and/or damage to the product.
- Distribute weight evenly across the product so that it cannot overturn.
- Do not place hot items such as coffee cups directly on the surface(s) unless adequately thick table mats are used.
- Please periodically check all fittings and re-tighten as necessary.
- For Indoor & Domestic use only.

Care instructions:

- Wipe clean with a dry cloth.
- Do not use scourers, abrasive or chemical solvents.
- Keep away from moisture and direct sunlight.
- Keep away from fire and inflammable objects.
- Store in a dry place.


SIGNATURE COLLECTION SEVILLE 2 DOOR TV UNIT

ITEM CODE: 435629



Assembly Instructions

SPECIAL TIPS FOR FITTING CAM-LOCKS AND QUICKFIT

CAM-LOCK




WHEN FITTING CAMLOCK
ENSURE STARTING POSITION IS CORRECT
BEFORE YOU INSERT CONNECTING QUICKFIT
TURN CLOCKWISE UNTIL SECURE



Quickfit head needs to be in centre

QUICKFIT


Tighten until shoulder is flush
with panel. Do not overtighten
or leave too loose.
(see example below)




SIGNATURE COLLECTION SEVILLE 2 DOOR TV UNIT

ITEM CODE: 435629
Assembly Instructions

STEP 1




STEP 2



SIGNATURE COLLECTION SEVILLE 2 DOOR TV UNIT


ITEM CODE: 435629
Assembly Instructions

STEP 3



C		4pcs	D		4pcs
---	---	------	---	---	------

STEP 4




B		8pcs	C		8pcs	O		4pcs
---	---	------	---	---	------	---	---	------



SIGNATURE COLLECTION SEVILLE 2 DOOR TV UNIT

ITEM CODE: 435629
Assembly Instructions

STEP 5



STEP 6




C		8pcs	I		1pcs
J		8pcs	O		4pcs

SIGNATURE COLLECTION SEVILLE 2 DOOR TV UNIT

ITEM CODE: 435629


Assembly Instructions

STEP 7



K		24pcs	G		6pcs
---	---	-------	---	---	------


STEP 8



SIGNATURE COLLECTION SEVILLE 2 DOOR TV UNIT



ITEM CODE: 435629
Assembly Instructions

STEP 9



N		4pcs
---	---	------

STEP 10




P		8pcs	Q		8pcs
---	---	------	---	---	------


SIGNATURE COLLECTION SEVILLE 2 DOOR TV UNIT

ITEM CODE: 435629
Assembly Instructions

STEP 11



STEP 12




E		4pcs	F		8pcs
---	---	------	---	---	------

SIGNATURE COLLECTION SEVILLE 2 DOOR TV UNIT

ITEM CODE: 435629
Assembly Instructions

STEP 13



How to Adjust Door Hinges


Adjust door up and down

Adjust door forward and back

Adjust door left and right

F		16pcs
---	--	-------

STEP 14




H		4pcs
---	--	------

SIGNATURE COLLECTION SEVILLE 2 DOOR TV UNIT


ITEM CODE: 435629

Assembly Instructions

STEP 15



STEP 16



B&M Retail, L24 8RJ, UK
www.bmstores.co.uk
B&M France SAS,
8 Rue du Bois Joli, 63800, France
MADE IN CHINA

Domestic Use Only