



HOME  
COLLECTION


## ARLO 2 DOOR TV UNIT

Item Code: 435633

### Assembly Instructions

**1.5 hrs**

APPROXIMATE ASSEMBLY TIME




2 PEOPLE ASSEMBLY

FLOOR AREA  
2M x 2M



REQUIRED ASSEMBLY SPACE


#### REQUIRED ASSEMBLY TOOL




SOFT RUBBER HAMMER (NOT PROVIDED)



SLOTTED SCREWDRIVER (NOT PROVIDED)




POZI SCREWDRIVER (NOT PROVIDED)



MEASURING TAPE (NOT PROVIDED)

#### ASSEMBLED DIMENSIONS




MAX LOADING: 40KG (TOP: 20KG / DRAWER: 5KG EACH / SHELF: 5KG EACH)

# HOME COLLECTION ARLO 2 DOOR TV UNIT

Item Code: 435633  
Assembly Instructions

## PART LIST





| NO. | PART LIST        | QTY | NO. | PART LIST        | QTY |
|-----|------------------|-----|-----|------------------|-----|
| ①   | TOP PANEL        | 1   | ⑨   | RIGHT SIDE PANEL | 1   |
| ②   | BOTTOM PANEL     | 1   | ⑩   | SHELF PANEL      | 1   |
| ③   | LEFT SIDE PANEL  | 1   | ⑪   | BOTTOM PANEL     | 1   |
| ④   | MIDDLE PANEL     | 1   | ⑫   | BACK PANEL       | 1   |
| ⑤   | RIGHT SIDE PANEL | 1   | ⑬   | METAL LEG        | 4   |
| ⑥   | BACK PANEL       | 1   | ⑭   | METAL LEG        | 2   |
| ⑦   | TOP PANEL        | 1   | ⑮   | METAL LEG        | 2   |
| ⑧   | LEFT SIDE PANEL  | 1   | ⑯   | DRAWER PANEL     | 2   |







# HOME COLLECTION ARLO 2 DOOR TV UNIT

Item Code: 435633  
Assembly Instructions

## HARDWARE LIST

| A                                                                                 | x 2 | B                                                                                 | x 4 | C                                                                                 | x 14 | D                                                                                 | x 14 | E                                                                                   | x 12 | F                                                                                                     | x 10 |
|-----------------------------------------------------------------------------------|-----|-----------------------------------------------------------------------------------|-----|-----------------------------------------------------------------------------------|------|-----------------------------------------------------------------------------------|------|-------------------------------------------------------------------------------------|------|-------------------------------------------------------------------------------------------------------|------|
|  |     |  |     |  |      |  |      |  |      | <br><b>M4x40mm</b> |      |
| HANDLE                                                                            |     | HINGE                                                                             |     | QUICK FIT                                                                         |      | CAM LOCK                                                                          |      | WOODEN DOWEL                                                                        |      | SCREW                                                                                                 |      |

| G                                                                                  | x 8 | H                                                                                  | x 24 | I                                                                                  | x 1 | J                                                                                  | x 2 | K                                                                                    | x 2 | L                                                                                                      | x 16 |
|------------------------------------------------------------------------------------|-----|------------------------------------------------------------------------------------|------|------------------------------------------------------------------------------------|-----|------------------------------------------------------------------------------------|-----|--------------------------------------------------------------------------------------|-----|--------------------------------------------------------------------------------------------------------|------|
|  |     |  |      |  |     |  |     |  |     | <br><b>M4x30mm</b> |      |
| SCREW                                                                              |     | SCREW                                                                              |      | ALLEN KEY                                                                          |     | SCREW                                                                              |     | SCREW                                                                                |     | SCREW                                                                                                  |      |

# HOME COLLECTION ARLO 2 DOOR TV UNIT

Item Code: 435633  
Assembly Instructions



## Safety Advice and Care Advice

KEEP ALL THE SAFETY ADVICE AND INSTRUCTIONS IN A SAFE PLACE FOR FUTURE REFERENCE!



### **WARNING! RISK OF LOSS OF LIFE OR ACCIDENT**

**TO INFANTS AND CHILDREN!** Never leave children unsupervised with the packaging materials. Danger of suffocation.

**CAUTION! RISK OF INJURY!** Make sure that all parts are undamaged and assembled correctly. Improper assembly carries a risk of injury. Damaged parts may affect the safety and function of the product.

- Adult assembly required.
- Power tools are not recommended for the assembly of this product.
- Make sure that this product is stable & used only on a solid & flat surface.
- Do not use this product unless all screws and fixings are firmly secured.
- Do not leave children unsupervised! The product is not a climbing frame or a toy!
- Do not stand, sit or lean on this product
- Do not use this product as a step ladder or as a chopping surface.
- Do not lift or move the product when it is loaded.
- Do not load more than a total of 40kg (Top: 20kg / Drawer: 5kg Each / Shelf: 5kg Each) onto the unit, otherwise there is a risk of injury and/or damage to the product
- Distribute weight evenly across the product so that it cannot overturn.
- Do not place hot items such as coffee cups directly on the surface(s) unless adequately thick table mats are used.
- Please periodically check all fittings and re-tighten as necessary.
- For Indoor & Domestic use only.

### **Care instructions:**


- Wipe clean with a dry cloth.
- Do not use scourers, abrasive or chemical solvents.
- Keep away from moisture and direct sunlight.
- Keep away from fire and inflammable objects.
- Store in a dry place.

# HOME COLLECTION ARLO 2 DOOR TV UNIT



Item Code: 435633  
Assembly Instructions

## SPECIAL TIPS FOR FITTING CAM-LOCKS AND QUICKFIT

### CAM-LOCK




WHEN FITTING CAMLOCK  
ENSURE STARTING POSITION IS CORRECT  
BEFORE YOU INSERT CONNECTING QUICKFIT  
TURN CLOCKWISE UNTIL SECURE



Quickfit head needs to be in centre

### QUICKFIT


Tighten until shoulder is flush with panel. Do not overtighten or leave too loose. (see example below)




# HOME COLLECTION ARLO 2 DOOR TV UNIT

Item Code: 435633  
Assembly Instructions


## STEP 1



G x 8




I x 1




## STEP 2



C x 10




E x 5



# HOME COLLECTION ARLO 2 DOOR TV UNIT

Item Code: 435633  
Assembly Instructions

## STEP 3



C x 4




D x 4



E x 2

## STEP 4




D x 4


# HOME COLLECTION ARLO 2 DOOR TV UNIT

Item Code: 435633  
Assembly Instructions

## STEP 5





E x 2



M4x40mm  
F x 4

## STEP 6




M4x30mm  
L x 8



# HOME COLLECTION ARLO 2 DOOR TV UNIT



Item Code: 435633  
Assembly Instructions

## STEP 7




D x 6

## STEP 8



E x 3




M4x40mm  
F x 6


# HOME COLLECTION ARLO 2 DOOR TV UNIT

Item Code: 435633  
Assembly Instructions


## STEP 9



M4x30mm  
L x 8




## STEP 10



J x 2





K x 2



# HOME COLLECTION ARLO 2 DOOR TV UNIT




Item Code: 435633  
Assembly Instructions

## STEP 11



X2

## STEP 12



X2



# HOME COLLECTION ARLO 2 DOOR TV UNIT

Item Code: 435633  
Assembly Instructions


## STEP 13



H x 16



## STEP 14



Domestic Use Only

B&M Retail, L24 8RJ, UK  
[www.bmstores.co.uk](http://www.bmstores.co.uk)  
B&M France SAS, 8 Rue du Bois Joli, 63800, France  
MADE IN CHINA