




KRISTEN SIDEBOARD

ITEM CODE: 435642
Assembly Instructions


1hr

APPROXIMATE ASSEMBLY TIME

2 PEOPLE ASSEMBLY




FLOOR AREA
2M x 2M




REQUIRED ASSEMBLY SPACE

REQUIRED ASSEMBLY TOOLS




POZI SCREWDRIVER (NOT PROVIDED)



MEASURING TAGE (NOT PROVIDED)

ASSEMBLED DIMENSIONS



Max. Loading: 30kg (Top: 10kg, Shelf: 5kg each)

SIGNATURE COLLECTION KRISTEN SIDEBOARD


Item Code: 435642

Assembly Instructions

PART LIST

ITEM CODE:










NO	PART LIST	QTY	NO	PART LIST	QTY
①	TOP PANEL	1	⑦	BACK PANEL	2
②	BOTTOM PANEL	1	⑧	BACK SLAT	1
③	LEFT SIDE PANEL	1	⑨	FRONT LEG	2
④	RIGHT SIDE PANEL	1	⑩	BACK LEG	2
⑤	MIDDLE PANEL	1	⑪	DOOR	2
⑥	SHELF	2			



SIGNATURE COLLECTION KRISTEN SIDEBORD

Item Code: 435642

Assembly Instructions

A	x6	B	x6	C	x12	D	x2	E	x6
									
Ø6x35mm		Ø15x12mm		Ø8x30mm		Ø6x30mm		Ø5x45mm	
QUICK FIT		CAM LOCK		DOWEL		DOWEL		SCREW	
F	x16	G	x4	H	x8	J	x2	K1	x2
									
M6x12mm		Ø4x8mm		Ø3.5x18mm		Ø3.5x35mm		110x16x10mm	
SCREW		SCREW		SCREW		SCREW		HANDLE	
K2	x2	L	x8	M	x1	N	x8	P	x2
									
110x16x10mm		15x13x10mm		4mm		Ø5x16mm		Ø25x10mm	
HANDLE		BACK PANEL BUCKLE		ALLEN KEY		SHELF HOLDER		ADJUSTABLE FEET	
Q	x1	R	x2						
									
75x22x3mm									
FELT PAD		WALL FIXING							

SIGNATURE COLLECTION KRISTEN SIDEBORD

Item Code: 435642

Assembly Instructions



Safety Advice and Care Advice

KEEP ALL THE SAFETY ADVICE AND INSTRUCTIONS IN A SAFE PLACE FOR FUTURE REFERENCE!



WARNING! RISK OF LOSS OF LIFE OR ACCIDENT

TO INFANTS AND CHILDREN! Never leave children unsupervised with the packaging materials. Danger of suffocation.



CAUTION! RISK OF INJURY! Make sure that all parts are undamaged and assembled correctly. Improper assembly carries a risk of injury. Damaged parts may affect the safety and function of the product.

- Adult assembly required.
- Power tools are not recommended for the assembly of this product.
- Make sure that this product is stable & used only on a solid & flat surface.
- Do not use this product unless all screws and fixings are firmly secured.
- Do not leave children unsupervised! The product is not a climbing frame or a toy!
- Do not stand, sit or lean on this product
- Do not use this product as a step ladder or as a chopping surface.
- Do not lift or move the product when it is loaded.
- Do not load more than a total of 30kg (top: 10kg, shelf: 5kg each) onto the unit, otherwise there is a risk of injury and/or damage to the product
- Distribute weight evenly across the product so that it cannot overturn.
- Do not place hot items such as coffee cups directly on the surface(s) unless adequately thick table mats are used.
- Please periodically check all fittings and re-tighten as necessary.
- For Indoor & Domestic use only.

Care instructions:

- Wipe clean with a dry cloth.
- Do not use scourers, abrasive or chemical solvents.
- Keep away from moisture and direct sunlight.
- Keep away from fire and inflammable objects.


SIGNATURE COLLECTION KRISTEN SIDEBOARD

Item Code: 435642



Assembly Instructions

SPECIAL TIPS FOR FITTING CAM-LOCKS AND QUICKFIT

CAM-LOCK




WHEN FITTING CAMLOCK
ENSURE STARTING POSITION IS CORRECT
BEFORE YOU INSERT CONNECTING QUICKFIT
TURN CLOCKWISE UNTIL SECURE



Quickfit head needs to be in centre

QUICKFIT

Tighten until shoulder is flush with panel. Do not overtighten or leave too loose. (see example below)



SIGNATURE COLLECTION KRISTEN SIDEBORD

Item Code: 435642

Assembly Instructions

NOTE: Supplied wall plugs are only suitable for use in masonry walls.

If you have any doubts about using the correct plug for your wall, please seek professional advice. Failure of the product due to using incorrect fixings is the responsibility of the installer.



IMPORTANT:

When drilling into walls, always check for hidden wires or pipes, etc.



Tips & Tricks


Make sure that the hardware used is suitable for supporting your unit.

Please consult a qualified tradesperson if unsure.

- ✓ If you are unsure, please select a larger screw and wall plug.
- ✓ Ensure that you use the recommended drill bit to match the wall plug and hole size.
- ✓ Take extra care when drilling high walls, ceiling and ceramic tiles. Ensure wall plugs are inserted beyond the thickness of the ceramic tiles to avoid splitting or cracking.
- ✓ Ensure that wall plugs are well fitted and are a tight fit in the drilled hole.


Types Of Walls

Use one of the following types of wall plug (not included) if your walls are made of brick, breeze block, concrete, stone or wood. Screws may be able to be fixed directly to solid wood walls as they will provide a secure anchor point.




1. General Purpose Wall Plug

Generally, aerated blocks should not be used to support heavy loads, use a specialist fitting in this case. For light loads, general purpose wall plugs can be used.




2. Plasterboard Wall Plug

For use when attaching light loads onto plasterboard partitions.




3. Cavity Fixing Wall Plug

For use with plasterboard partitions or hollow wooden doors.




4. Cavity Fixing Heavy Duty Wall Plug

For use when fitting or supporting heavy loads such as shelving and wall cabinets.



5. Hammer Fixing Wall Plug

For use with concrete block or brick walls, or walls stuck with plasterboard. The hammer fixing allows it to be fixed to the wall rather than the plasterboard. Always check the fixing is secure to the retaining wall.



6. Shield Anchor Wall Plug Heavy Loads

For use with concrete or brick walls, or for use with heavier loads such as TV & HiFi speakers and satellite dishes, etc.

SIGNATURE COLLECTION KRISTEN SIDEBOARD


Item Code: 435642

Assembly Instructions


STEP 1




Ø8x30mm
C x 12



STEP 2



Ø6x35mm
A x 6




SIGNATURE COLLECTION KRISTEN SIDEBOARD


Item Code: 435642

Assembly Instructions

STEP 3



STEP 4



SIGNATURE COLLECTION KRISTEN SIDEBOARD


Item Code: 435642

Assembly Instructions

STEP 5



Ø 5x45mm
E x 6





STEP 6



Ø 3.5x18mm
H x 8



15x13x10mm
L x 8








SIGNATURE COLLECTION KRISTEN SIDEBORD



Item Code: 435642

Assembly Instructions

STEP 7



STEP 8




SIGNATURE COLLECTION KRISTEN SIDEBOARD


Item Code: 435642

Assembly Instructions

STEP 9



STEP 10



Ø6x30mm
D x 2




75x22x3mm
Q x 1

SIGNATURE COLLECTION KRISTEN SIDEBOARD


Item Code: 435642

Assembly Instructions

STEP 11



STEP 12



M6x12mm
F x 16

4mm
M x 1

Ø25x10mm
P x 2

SIGNATURE COLLECTION KRISTEN SIDEBOARD


Item Code: 435642

Assembly Instructions


STEP 13



Ø5x16mm
N x 8



STEP 14




SIGNATURE COLLECTION KRISTEN SIDEBORD

Item Code: 435642

Assembly Instructions

STEP 15







adjustable feet

SIGNATURE COLLECTION KRISTEN SIDEBOARD

Item Code: 435642

Assembly Instructions

STEP 16




WARNING: Anti-tipping hardware is only a deterrent. It is not a substitute for proper adult supervision.

Young children may be injured by tipping furniture and the use of a tipping restraint is highly recommended.

This hardware, when properly installed, could provide protection against the unexpected tipping of furniture due to improper use.

Please ensure the anti-tipping hardware provided is suitable for your wall or else, it might damage your wall during installation.



Domestic use only



B&M Retail, L24 8RJ, UK
www.bmstores.co.uk

B&M France SAS, 8 Rue du Bois Joli, 63800, France
MADE IN CHINA