



DINING
COLLECTION


ARDEN DINING TABLE

ITEM CODE: 437439

Assembly Instructions

1 hr

APPROXIMATE ASSEMBLY TIME




2 PERSONS ASSEMBLY

FLOOR AREA
2M X 2M




REQUIRED ASSEMBLY SPACE


REQUIRED ASSEMBLY TOOLS



SLOTTED SCREWDRIVER (Not Provided)




POZI SCREWDRIVER (Not Provided)



MEASURING TAPE (Not Provided)

ASSEMBLED DIMENSIONS




MAX. LOADING: 100KG

DINING COLLECTION ARDEN DINING TABLE

ITEM CODE: 437439
Assembly Instructions

NO	PART LIST	QTY	NO	PART LIST	QTY
①	TABLE LEG	2	③	SUPPORTING BAR	1
②	CONNECTING PANEL	2	④	TABLE TOP	1






PART LIST



DINING COLLECTION ARDEN DINING TABLE

ITEM CODE: 437439
Assembly Instructions

HARDWARE LIST

A	x2	B	x2	C	x2	D	x4	E	x40
									
QUICK FIT		CAM LOCK		WOOD DOWEL		FLOOR PROTECTOR		SCREW M6 X 25mm	
F	x1	G	x4	H	x4	I	x4	J	x4
									
WRENCH		SCREW M6 X 120mm		WASHER		BARREL NUT DOWEL		COVER STICKER	

DINING COLLECTION ARDEN DINING TABLE

ITEM CODE: 437439

Assembly Instructions



Safety Advice and Care Advice

KEEP ALL THE SAFETY ADVICE AND INSTRUCTIONS IN A SAFE PLACE FOR FUTURE REFERENCE!



WARNING! RISK OF LOSS OF LIFE OR ACCIDENT

TO INFANTS AND CHILDREN! Never leave children unsupervised with the packaging materials. Danger of suffocation.



CAUTION! RISK OF INJURY! Make sure that all parts are undamaged and assembled correctly. Improper assembly carries a risk of injury. Damaged parts may affect the safety and function of the product.

- Adult assembly required.
- Power tools are not recommended for the assembly of this product.
- Make sure that this product is stable & used only on a solid & flat surface.
- Do not use this product unless all screws and fixings are firmly secured.
- Do not leave children unsupervised! The product is not a climbing frame or a toy!
- Do not stand, sit or lean on this product.
- Do not use this product as a step ladder or as a chopping surface.
- Do not lift or move the product when it is loaded.
- Do not load more than a total of 100KG, otherwise there is a risk of injury and/or damage to the product.
- Distribute weight evenly across the product so that it cannot overturn.
- Do not place hot items such as coffee cups directly on the surface(s) unless adequately thick table mats are used.
- Please periodically check all fittings and re-tighten as necessary.
- For Indoor & Domestic use only.

Care instructions:


- Wipe clean with a dry cloth.
- Do not use scourers, abrasive or chemical solvents.
- Keep away from moisture and direct sunlight.
- Keep away from fire and inflammable objects.
- Store in a dry place.

DINING COLLECTION ARDEN DINING TABLE



ITEM CODE: 437439
Assembly Instructions

SPECIAL TIPS FOR FITTING CAM-LOCKS AND QUICKFIT

CAM-LOCK




WHEN FITTING CAMLOCK
ENSURE STARTING POSITION IS CORRECT
BEFORE YOU INSERT CONNECTING QUICKFIT
TURN CLOCKWISE UNTIL SECURE



Quickfit head needs to be in centre

QUICKFIT



Tighten until shoulder is flush
with panel. Do not overtighten
or leave too loose.
(see example below)





DINING COLLECTION ARDEN DINING TABLE

ITEM CODE: 437439
Assembly Instructions

STEP 1




STEP 2



DINING COLLECTION ARDEN DINING TABLE


ITEM CODE: 437439
Assembly Instructions


STEP 3



E	x20	F	x1
			

STEP 4





F	x1
	
G	x4
	
H	x4
	
I	x4
	

DINING COLLECTION ARDEN DINING TABLE

ITEM CODE: 437439
Assembly Instructions

STEP 5



B	x2	C	x2	E	x20	F	x1
							




DINING COLLECTION ARDEN DINING TABLE

ITEM CODE: 437439
Assembly Instructions

STEP 6



STEP 7



B&M Retail, L24 8RJ, UK
www.bmstores.co.uk
B&M France SAS,
8 Rue du Bois Joli, 63800, France
MADE IN CHINA

Domestic Use Only